

2017 JET SKI® ULTRA® 310R




PARTS DIAGRAM

Handlebar

Kawasaki

Let the Good Times Roll®

F3172



2017 JET SKI® ULTRA® 310R

PARTS LIST

Handlebar

ITEM NAME	PART NUMBER	QUANTITY
BRACKET (Ref # 11056)	11056-2688	1
BOLT-SOCKET,8X40 (Ref # 120)	120R0840	4
SHAFT (Ref # 13107)	13107-3766	1
PLATE (Ref # 13272)	13272-1520	1
COVER,F.BLACK (Ref # 14092)	14092-1124-6Z	1
SCREW-PAN-CROS,5X14 (Ref # 220)	220R0514	1
SCREW-PAN-CROS,5X25 (Ref # 220A)	220R0525	2
SCREW-PAN-CROS,5X30 (Ref # 220B)	220R0530	3
SWITCH-ASSY,STOP&START (Ref # 27045)	27045-3767	1
HANDLE-COMP,F.BLACK (Ref # 39058)	39058-0021-6Z	1
LEVER-ASSY-THROTTLE (Ref # 39074)	39074-3729	1
LEVER-THROTTLE (Ref # 39075)	39075-3715	1
PAD-HANDLE (Ref # 39087A)	39087-0012	1
WASHER-PLAIN,8MM (Ref # 411)	411S0800	4
HOLDER-HANDLE,OFF SET 5MM (Ref # 46012)	46012-0333	2
HOLDER-HANDLE (Ref # 46012A)	46012-0334	2
HOLDER-HANDLE (Ref # 46012B)	46012-0336	2
HOLDER-HANDLE (Ref # 46012C)	46012-0339	1
WASHER-SPRING,8MM (Ref # 461)	461S0800	4
BOLT,6X12 (Ref # 92002)	92002-3763	1
RING-SNAP (Ref # 92033)	92033-3723	1
CLAMP,SPEED,L=58 (Ref # 92037)	92037-1163	3
RIVET (Ref # 92039)	92039-3785	4
GROMMET (Ref # 92071)	92071-3716	2
BAND,TETHER SWITCH (Ref # 92072)	92072-3809	1
BAND,L=372.24 (Ref # 92072A)	92072-3883	1
SPRING (Ref # 92144)	92144-3749	1
BOLT,8X30 (Ref # 92151)	92151-3771	4
COLLAR,12.5X28X5 (Ref # 92152)	92152-1850	4

2017 JET SKI® ULTRA® 310R

PARTS LIST

Handlebar

ITEM NAME	PART NUMBER	QUANTITY
DAMPER,SPEED CONTROL (Ref # 92160)	92160-1625	1
WASHER,10.5X24X1.5 (Ref # 92200)	92200-0154	2
WASHER (Ref # 92200A)	92200-3738	2
NUT,LOCK,10MM (Ref # 92210)	92210-3792	2