


2008 ZZR® 600

PARTS DIAGRAM

Transmission

Kawasaki

Let the Good Times Roll®



E1361

2008 ZZR® 600

PARTS LIST

Transmission

ITEM NAME	PART NUMBER	QUANTITY
BALL-STEEL,5/32" (Ref # 600)	600A0500	3
SHAFT-TRANSMISSION INPUT,13T (Ref # 13127)	13127-1298	1
SHAFT-TRANSMISSION OUTPUT (Ref # 13128)	13128-1264	1
SPROCKET-OUTPUT,15T (Ref # 13144)	13144-1288	1
GEAR,INPUT 2ND,16T (Ref # 13260)	13260-1452	1
GEAR,OUTPUT LOW,38T (Ref # 13260A)	13260-1456	1
GEAR,OUTPUT 2ND,33T (Ref # 13260B)	13260-1568	1
GEAR,OUTPUT 5TH,28T (Ref # 13260C)	13260-1979	1
GEAR,INPUT 3RD&4TH,19T&21T (Ref # 13260D)	13260-1980	1
GEAR,OUTPUT 4TH,29T (Ref # 13260E)	13260-1981	1
GEAR,INPUT 5TH,32T (Ref # 13260F)	13260-1982	1
GEAR,INPUT TOP,24T (Ref # 13260G)	13260-1983	1
GEAR,OUTPUT TOP,26T (Ref # 13260H)	13260-1984	1
GEAR,OUTPUT 3RD,31T (Ref # 13262)	13262-1058	1
BUSHING,INPUT 5TH GEAR (Ref # 92028)	92028-1735	1
BUSHING,INPUT TOP GEAR (Ref # 92028A)	92028-1736	1
BUSHING,OUTPUT,3RD&4TH (Ref # 92028B)	92028-1738	1
BUSHING,OUTPUT,2ND (Ref # 92028C)	92028-1739	1
RING-SNAP,20MM (Ref # 92033)	92033-015	2
RING-SNAP,24MM (Ref # 92033A)	92033-026	2
RING-SNAP,25.9X30.6X1.2 (Ref # 92033B)	92033-1037	3
BEARING-BALL,HR6205C3 (Ref # 92045)	92045-0009	1
BEARING-BALL,83993SH2-CS (Ref # 92045A)	92045-035	1
BEARING-NEEDLE,PK20X27X17X3 (Ref # 92046)	92046-1303	2
BUSHING,27X34X18.6 (Ref # 92139)	92139-1090	2
COLLAR,25X32X13 (Ref # 92152)	92152-0192	1
WASHER (Ref # 92200)	92200-1065	1
WASHER,20.3X30X2.3 (Ref # 92200A)	92200-1238	1
WASHER,25.2X31.0X1.5 (Ref # 92200B)	92200-1239	2

2008 ZZR[®] 600

PARTS LIST

Transmission



ITEM NAME	PART NUMBER	QUANTITY
WASHER,28.5X34.0X1.5 (Ref # 92200C)	92200-1240	3
WASHER,20.3X33X1.0 (Ref # 92200D)	92200-1613	1
NUT,SPROCKET (Ref # 92210)	92210-1098	1