

2003 KFX400


PARTS DIAGRAM

Starter Motor

Kawasaki

Let the Good Times Roll®

E1840



2003 KFX400

PARTS LIST

Starter Motor



ITEM NAME	PART NUMBER	QUANTITY
BRUSH,TERMINAL SET (Ref # 11021)	11021-S002	1
HOLDER-ASSY (Ref # 14079)	14079-S002	1
STARTER-ELECTRIC (Ref # 21163)	21163-S004	1
RING-O,D=3,ID=24.5 (Ref # 92055)	92055-S008	1
RING-O (Ref # 92055A)	92055-S067	1
RING-O (Ref # 92055B)	92055-S068	2
RING-O (Ref # 92055C)	92055-S069	2
SPRING,BRUSH (Ref # 92145)	92145-S103	2
BOLT (Ref # 92153)	92153-S003	2
BOLT (Ref # 92153A)	92153-S293	2
WASHER,SET (Ref # 92200)	92200-S154	1
NUT,STARTER MOTOR (Ref # 92210)	92210-S099	1