

Front Hub

Let the Good Times Roll®

This diagram illustrates the assembly of a vehicle wheel, showing the relationship between various components. The main components and their part numbers are as follows:

- 41080**: Wheel hub assembly.
- 92200 ('05)**: Wheel rim.
- 14091/A/B**: Wheel nut.
- 92153**: Wheel washer.
- 92153A**: Wheel washer.
- 92026A/C**: Wheel bearing.
- 92093A**: Wheel bearing.
- 92045A**: Wheel bearing.
- 92026B**: Wheel bearing.
- 41034**: Wheel hub assembly.
- 92045**: Wheel bearing.
- 92026**: Wheel bearing.
- 92093**: Wheel bearing.
- 13271**: Wheel hub assembly.
- 41025/A**: Wheel hub assembly.
- 92210A/B**: Wheel nut.
- 92210**: Wheel nut.
- 92200A**: Wheel rim.
- 39092**: Wheel nut.
- 16126**: Wheel nut.
- 41009**: Wheel hub assembly.

The diagram also includes a **FRONT** arrow indicating the orientation of the wheel assembly.

2003 KFX400

PARTS LIST

Front Hub

ITEM NAME	PART NUMBER	QUANTITY
PLATE (Ref # 13271)	13271-S053	2
COVER,FRONT DISC (Ref # 14091)	14091-S091	2
VALVE,WHEEL RIM,TR412 (Ref # 16126)	16126-S002	2
PIN-HAIR (Ref # 39092)	39092-S007	2
TIRE,FR (Ref # 41009)	41009-S012	2
RIM,FRONT WHEEL,10X5.5AT (Ref # 41025)	41025-S008	2
DRUM-ASSY,FR,F.GRAY (Ref # 41034)	41034-S005-563	2
DISC,FRONT BRAKE (Ref # 41080)	41080-S005	2
SPACER (Ref # 92026)	92026-S090	2
SPACER (Ref # 92026A)	92026-S091	2
SPACER (Ref # 92026B)	92026-S097	2
BEARING-BALL,FRONT HUB (Ref # 92045)	92045-S036	2
BEARING-BALL,FRONT HUB (Ref # 92045A)	92045-S048	2
SEAL (Ref # 92093)	92093-S033	2
SEAL (Ref # 92093A)	92093-S034	2
BOLT,FRONT DISC COVER (Ref # 92153)	92153-S258	6
BOLT (Ref # 92153A)	92153-S283	6
WASHER,FRONT AXLE (Ref # 92200A)	92200-S099	2
NUT,FRONT AXLE (Ref # 92210)	92210-S075	2
NUT,WHEEL (Ref # 92210A)	92210-S100	8