

Front Hub

Let the Good Times Roll®

Exploded view diagram of a wheel assembly, showing the front and rear views of the wheel and its associated components. The diagram includes the following labeled parts:

- Front View Components:**
 - 11065 (Hub)
 - 39092 (Pin)
 - 92210A (Washer)
 - 92200A (Washer)
 - 92026A (Washer)
 - 92210/B (Washer)
 - 92200 (Washer)
 - 41009 (Wheel Rim)
 - 41025 (Wheel Hub)
 - 92045 (Washer)
 - 41034 (Hub Nut)
 - 92049/B (Washer)
 - 92045A (Washer)
 - 92049A (Washer)
 - 92026 (Washer)
- Rear View Components:**
 - 16126 (Pin)
 - 92200A (Washer)
 - 92210A (Washer)
 - 39092 (Pin)
 - 11065 (Hub)
 - 92026A (Washer)
 - 92200 (Washer)
 - 92210/B (Washer)

The diagram also includes a "FRONT" arrow indicating the orientation of the wheel.

2005 KFX50

PARTS LIST

Front Hub

ITEM NAME	PART NUMBER	QUANTITY
CAP,WHEEL (Ref # 11065)	11065-S022	2
VALVE,WHEEL RIM,TR412 (Ref # 16126)	16126-S002	2
PIN-HAIR (Ref # 39092)	39092-S007	2
TIRE (Ref # 41009)	41009-S009	2
RIM,FRONT WHEEL,B.SILVER (Ref # 41025)	41025-S005-530	2
DRUM-ASSY,FR (Ref # 41034)	41034-S003	2
SPACER,FRONT HUB BEARING (Ref # 92026)	92026-S061	2
SPACER,FRONT AXLE (Ref # 92026A)	92026-S062	2
BEARING-BALL,FRONT HUB (Ref # 92045)	92045-S036	2
BEARING-BALL,FRONT HUB (Ref # 92045A)	92045-S037	2
SEAL-OIL,FRONT HUB (Ref # 92049A)	92049-S032	2
SEAL-OIL,FRONT HUB BRG (Ref # 92049B)	92049-S063	2
WASHER,WHEEL NUT (Ref # 92200)	92200-S098	6
WASHER,FRONT AXLE (Ref # 92200A)	92200-S099	2
NUT,FRONT AXLE (Ref # 92210A)	92210-S075	2
NUT (Ref # 92210B)	92210-S094	6