

2003 KFX80


PARTS DIAGRAM

Starter Motor

Kawasaki

Let the Good Times Roll®

E1840



2003 KFX80

PARTS LIST

Starter Motor

ITEM NAME	PART NUMBER	QUANTITY
CASE-ASSY (Ref # 11021)	11021-S001	1
GASKET (Ref # 11061)	11061-S063	1
GASKET (Ref # 11061A)	11061-S068	1
ARMATURE (Ref # 21080)	21080-S001	1
STARTER-ELECTRIC (Ref # 21163)	21163-S003	1
WIRE-LEAD (Ref # 26011)	26011-S009	1
LIMITER,PINION (Ref # 39076)	39076-S003	1
RING-O (Ref # 92055)	92055-S046	1
SPRING,BRUSH (Ref # 92145)	92145-S077	2
CLAMP,L=125 (Ref # 92171)	92171-S014	1
CLAMP,LEAD WIRE (Ref # 92171A)	92171-S078	1
SCREW (Ref # 92172)	92172-S145	2
SCREW (Ref # 92172A)	92172-S146	1
SCREW (Ref # 92172B)	92172-S147	3