


1999 Prairie 300

PARTS DIAGRAM

Ignition Switch



1999 Prairie 300

PARTS LIST

Ignition Switch

ITEM NAME	PART NUMBER	QUANTITY
SWITCH-COMP,D.C.TERMINAL (Ref # 13151)	13151-1087	1
COVER,KEY (Ref # 14024)	14024-1551	4
LAMP-ASSY,NEUTRAL&REVERSE (Ref # 23016)	23016-1083	1
SWITCH-ASSY-IGNITION (Ref # 27005)	27005-1201	1
KEY-LOCK,BLANK (Ref # 27008)	27008-1041	1
KEY-LOCK,BLANK (Ref # 27008A)	27008-1042	1
KEY-LOCK,BLANK (Ref # 27008B)	27008-1043	1
KEY-LOCK,BLANK (Ref # 27008C)	27008-1044	1
KEY-LOCK,BLANK,W/COVER (Ref # 27008D)	27008-1132	1
KEY-LOCK,BLANK,W/COVER (Ref # 27008E)	27008-1133	1
KEY-LOCK,BLANK,W/COVER (Ref # 27008F)	27008-1134	1
KEY-LOCK,BLANK,W/COVER (Ref # 27008G)	27008-1135	1
BULB,12V 3W,T7 (Ref # 92069)	92069-1020	2
NUT,IGNITION SWITCH (Ref # 92210)	92210-1109	1