


2001 Prairie 400

PARTS DIAGRAM

Chassis Electrical Equipment

Kawasaki

Let the Good Times Roll®



2001 Prairie 400

PARTS LIST

Chassis Electrical Equipment

ITEM NAME	PART NUMBER	QUANTITY
BOLT-FLANGED,6X12 (Ref # 130)	130B0612	1
CAP,TERMINAL (Ref # 11012)	11012-1354	1
FUSE-ASSY (Ref # 26004)	26004-1104	1
FUSE-ASSY (Ref # 26004A)	26004-1114	1
FUSE-ASSY (Ref # 26004B)	26004-3715	1
FUSE,30A,L=30 (Ref # 26006)	26006-1059	2
FUSE,8A,L=30 (Ref # 26006A)	26006-1062	2
FUSE,5A,L=30 (Ref # 26006B)	26006-1074	2
WIRE-LEAD,BATTERY(+) (Ref # 26011)	26011-1513	1
WIRE-LEAD,BATTERY(-) (Ref # 26011A)	26011-1637	1
WIRE-LEAD,ACCESSORY CONNECT (Ref # 26011B)	26011-1763	AR
HARNESS,MAIN (Ref # 26030A)	26030-1783	1
RELAY-ASSY (Ref # 27002)	27002-1095	1
CLAMP,SPEED,L=80.5 (Ref # 92037)	92037-1903	2
BAND,L=186 (Ref # 92072A)	92072-056	1
COVER,COUPLER (Ref # 14090)	14090-1331	4
COVER,COUPLER (Ref # 14090)	14090-1331	5
BATTERY,YTX14-BS,12V 12AH (Ref # 26012A)	26012-1302	1
BATTERY,YB14A-A2,12V 14AH (Ref # 26012B)	26012-1388	1
BAND,L=123 (Ref # 92072)	92072-030	6
BAND,L=123 (Ref # 92072)	92072-030	8
BAND,L=188 (Ref # 92072B)	92072-1239	15
BAND,L=188 (Ref # 92072B)	92072-1239	16