

Front Hub

Let the Good Times Roll®

This diagram illustrates the assembly of a mechanical component, likely a valve or actuator, showing various parts and their assembly sequence. The components are labeled with part numbers:

- 11065**: A small cylindrical component at the top left.
- 92200** and **92210**: Small circular components below 11065.
- 92152**: A small circular component below 92200.
- 41009**: A large, flange-like component in the upper center.
- 16126**: A small, curved component near the bottom of 41009.
- 41025/A**: A threaded component below 41009.
- 41036/A**: A rectangular component box in the center, containing:
 - 92153**: A small circular component.
 - 92093**: A small circular component.
 - 92045A**: A small circular component.
 - 92045**: A small circular component.
 - 92152A**: A small circular component.
- 41047**: A rectangular component box on the right, containing:
 - 92145**: A small circular component.
- 92145A**: A small circular component on the far right.
- 41050**: A small, curved component on the right.
- 21083A**: A small, curved component on the far right.
- 41035A**: A small, curved component on the far right.
- 41047**: A rectangular component box on the left, containing:
 - 92145**: A small circular component.
- 41036/A**: A rectangular component box at the bottom center, containing:
 - 92093**: A small circular component.
 - 92152A**: A small circular component.
 - 92045**: A small circular component.
 - 92045A**: A small circular component.
 - 92153**: A small circular component.
- 41025/A**: A threaded component at the bottom center.
- 41009**: A large, flange-like component at the bottom right.
- 16126**: A small, curved component near the bottom of 41025/A.
- 92152**: A small circular component at the bottom right.
- 92210**: A small circular component at the bottom right.
- 11065**: A small cylindrical component at the bottom right.



2013 KFX[®]90

PARTS LIST

Front Hub

ITEM NAME	PART NUMBER	QUANTITY
CAP,WHEEL (Ref # 11065)	11065-Y002	2
VALVE,RIM (Ref # 16126)	16126-Y001	2
ARM,BRAKE,RH (Ref # 21083)	21083-Y001	1
ARM,BRAKE,LH (Ref # 21083A)	21083-Y002	1
TIRE,FR (Ref # 41009)	41009-Y003	2
RIM,SILVER (Ref # 41025A)	41025-Y003-936	2
PANEL-ASSY-BRAKE,FR,RH,SILVER (Ref # 41035)	41035-Y001-934	1
PANEL-ASSY-BRAKE,FR,LH,SILVER (Ref # 41035A)	41035-Y002-934	1
HUB-ASSY,FR,SILVER (Ref # 41036A)	41036-Y002-936	2
SHOE-ASSY-BRAKE,FR (Ref # 41047)	41047-Y001	2
CAM-BRAKE (Ref # 41050)	41050-Y001	2
BEARING-BALL,6002 (Ref # 92045)	92045-Y010	2
BEARING-BALL,6003 (Ref # 92045A)	92045-Y011	2
SEAL,22X35X7 (Ref # 92093)	92093-Y008	4
SPRING,BRAKE SHOE (Ref # 92145)	92145-Y013	2
SPRING,RETURN (Ref # 92145A)	92145-Y014	2
COLLAR (Ref # 92152)	92152-Y008	2
COLLAR (Ref # 92152A)	92152-Y009	2
BOLT,STUD,10X17 (Ref # 92153)	92153-Y017	8
BOLT,FLANGE,5X24 (Ref # 92153A)	92153-Y021	2
WASHER,12MM (Ref # 92200)	92200-Y011	2
NUT,10MM (Ref # 92210)	92210-Y010	8