

Cylinder Head

Let the Good Times Roll®

This diagram illustrates the assembly of a 6-cylinder engine. The main components and their associated part numbers are as follows:

- 11001**: The main engine block, shown in an exploded view.
- 92154A**: Four bolts used for securing the top of the engine block.
- 92154B**: A single bolt used for securing the top of the engine block.
- 92200**: A washer or spacer used in conjunction with the 92154B bolt.
- 92043**: Two spacers or washers used for alignment or spacing.
- 42036**: A cylindrical component, likely a filter or a part of the cooling system.
- 92154**: A bolt used for securing the side of the engine block.
- 11056**: A bracket or support arm used for mounting the engine.
- 92004**: A small pin or clip used for securing the side of the engine block.
- 92210**: A small pin or clip used for securing the side of the engine block.
- 49002**: Two small cylindrical components, likely spacers or washers, used for securing the bottom of the engine block.
- 11004**: A gasket or seal used for the bottom of the engine block.



2017 Mule PRO-FXT EPS LE

PARTS LIST

Cylinder Head

ITEM NAME	PART NUMBER	QUANTITY
HEAD-CYLINDER (Ref # 11001)	11001-0839	1
GASKET-HEAD (Ref # 11004)	11004-0747	1
BRACKET (Ref # 11056)	11056-7081	1
BRACKET (Ref # 11056A)	11056-7082	1
SLEEVE,SPARK PLUG (Ref # 42036)	42036-0764	3
GUIDE-VALVE (Ref # 49002)	49002-0030	12
STUD (Ref # 92004)	92004-0734	1
PIN (Ref # 92043)	92043-0831	8
BOLT,FLANGED,8X16 (Ref # 92154)	92154-1588	2
BOLT,6X38 (Ref # 92154A)	92154-1589	17
BOLT,SOCKET (Ref # 92154B)	92154-1590	8
WASHER (Ref # 92200)	92200-1683	8
NUT (Ref # 92210)	92210-0944	1