


2018 VERSYS®-X 300 ABS

Kawasaki
Let the Good Times Roll®

PARTS DIAGRAM

Accessory(DC Socket)

F2910D



2018 VERSYS®-X 300 ABS

PARTS LIST

Accessory(DC Socket)

ITEM NAME	PART NUMBER	QUANTITY
SWITCH-COMP,DC SOCKET (Ref # 13151)	13151-0566	1
BAND,OS170-FT7(BLACK) (Ref # 92072)	92072-1414	1
KIT-ACCESSORY,DC SOCKET (Ref # 99994)	99994-0997	1