


# 2001 KX250

## PARTS DIAGRAM

### Footrests



# 2001 KX250

## PARTS LIST

### Footrests



| ITEM NAME                      | PART NUMBER   | QUANTITY |
|--------------------------------|---------------|----------|
| PIN-COTTER,3.0X20 (Ref # 550)  | 550S3020      | 2        |
| STEP,LH,SILVER (Ref # 34028)   | 34028-1475-CE | 1        |
| STEP,RH,SILVER (Ref # 34028A)  | 34028-1476-CE | 1        |
| WASHER,10.2X16X1 (Ref # 92022) | 92022-1829    | 2        |
| PIN,10X49.5 (Ref # 92043)      | 92043-1564    | 2        |
| SPRING,STEP,LH (Ref # 92145)   | 92145-1351    | 1        |
| SPRING,STEP,RH (Ref # 92145A)  | 92145-1352    | 1        |