

Transmission

Let the Good Times Roll®

Exploded view diagram of a mechanical assembly, likely a transmission or gearbox, showing various components and their assembly sequence. The diagram includes a "FRONT" arrow pointing left.

Key components and part numbers shown:

- Input Shaft (13127):** The main shaft at the top right, with a gear (13262I) at the front and a bearing (92045) at the rear.
- Intermediate Shaft (13128):** The central shaft, with a gear (13262H) at the front and a bearing (92045A) at the rear.
- Output Shaft (13128):** The bottom shaft, with a gear (13262) at the front and a bearing (92045B) at the rear.
- Gears:** Various gears are shown, including 13262E, 13262F, 13262G/J, 13262H, 13262I, 13262A, 13262B, 13262C, 13262D/K, 13262J, 13262K, 13262L, 13262M, 13262N, 13262O, 13262P, 13262Q, 13262R, 13262S, 13262T, 13262U, 13262V, 13262W, 13262X, 13262Y, 13262Z.
- Bearings:** Various bearings are shown, including 92045, 92045A, 92045B, 92045C, 92045D, 92045E, 92045F, 92045G, 92045H, 92045I, 92045J, 92045K, 92045L, 92045M, 92045N, 92045O, 92045P, 92045Q, 92045R, 92045S, 92045T, 92045U, 92045V, 92045W, 92045X, 92045Y, 92045Z.
- Other Components:** Various other components are shown, including 92033, 92033A, 92033B, 92033C, 92033D, 92033E, 92033F, 92033G, 92033H, 92033I, 92033J, 92033K, 92033L, 92033M, 92033N, 92033O, 92033P, 92033Q, 92033R, 92033S, 92033T, 92033U, 92033V, 92033W, 92033X, 92033Y, 92033Z.

2011 NINJA® ZX™-10R

PARTS LIST

Transmission

ITEM NAME	PART NUMBER	QUANTITY
SHAFT-TRANSMISSION INPUT (Ref # 13127)	13127-0636	1
SHAFT-TRANSMISSION OUTPUT (Ref # 13128)	13128-0670	1
SPROCKET-OUTPUT,17T,#525 (Ref # 13144)	13144-0004	1
GEAR,OUTPUT LOW,39T (Ref # 13262)	13262-0615	1
GEAR,OUTPUT 3RD,33T (Ref # 13262A)	13262-0803	1
GEAR,OUTPUT 4TH,33T (Ref # 13262B)	13262-0804	1
GEAR,OUTPUT 5TH,26T (Ref # 13262C)	13262-0805	1
GEAR,OUTPUT TOP,31T (Ref # 13262D)	13262-0806	1
GEAR,INPUT 2ND,19T (Ref # 13262E)	13262-0856	1
GEAR,INPUT TOP,23T (Ref # 13262F)	13262-0869	1
GEAR,OUTPUT 2ND,39T (Ref # 13262G)	13262-0880	1
GEAR,INPUT 5TH,18T (Ref # 13262H)	13262-0881	1
GEAR,INPUT 3RD&4TH,19T&21T (Ref # 13262I)	13262-0891	1
NUT,20MM (Ref # 92015)	92015-1963	1
RING-SNAP,25.9X30.6X1.2 (Ref # 92033)	92033-1037	5
RING-SNAP,T=1.5 (Ref # 92033A)	92033-1249	1
BEARING-BALL,830045-5SH2 (Ref # 92045)	92045-0047	1
BEARING-BALL,DG2152RDDSH2 (Ref # 92045A)	92045-0048	1
BEARING-BALL,63/22LU (Ref # 92045B)	92045-0156	1
BEARING-BALL,63/28 (Ref # 92045C)	92045-1189	1
RING-O,21.5X1.5 (Ref # 92055)	92055-1293	1
BUSHING,GEAR,6TH IN (Ref # 92139)	92139-0036	1
BUSHING,GEAR,LOW OUT (Ref # 92139A)	92139-0038	1
BUSHING,25.0X31.0X9.4 (Ref # 92139B)	92139-0309	2
BUSHING,28.1X31.0X13.5 (Ref # 92139C)	92139-0324	1
BUSHING,28.1X31.0X11.5 (Ref # 92139D)	92139-0734	1
COLLAR (Ref # 92152)	92152-0885	1
WASHER,28.3X34.0X1.6 (Ref # 92200)	92200-0050	5
WASHER,22.1X32.0X1.4 (Ref # 92200A)	92200-0138	2

2011 NINJA[®] ZX[™]-10R

PARTS LIST

Transmission

ITEM NAME	PART NUMBER	QUANTITY
WASHER (Ref # 92200B)	92200-1065	1
WASHER,25.8X40.5X1.5 (Ref # 92200C)	92200-1522	2
WASHER,25.2X37.0X1.0 (Ref # 92200D)	92200-1523	2
BALL-STEEL,5/32 (Ref # 600)	600A0500	3