


2014 VERSYS®

PARTS DIAGRAM

Ignition Switch

Kawasaki

Let the Good Times Roll®



2014 VERSYS®

PARTS LIST

Ignition Switch

ITEM NAME	PART NUMBER	QUANTITY
ROTOR,LOCK,TANK CAP (Ref # 21007)	21007-5057	1
SWITCH-ASSY-IGNITION (Ref # 27005)	27005-5141	1
KEY-LOCK,BLANK (Ref # 27008)	27008-0030	1
SWITCH,REAR BRAKE (Ref # 27010)	27010-0095	1
SWITCH,SIDE STAND (Ref # 27010A)	27010-0097	1
LOCK-ASSY,SEAT STRIKER (Ref # 27016)	27016-0008	1
LOCK-ASSY,SEAT (Ref # 27016A)	27016-5309	1
SWITCH-ASSY (Ref # 27045)	27045-5360	1
REFLECTOR-REFLEX,FR,SIDE (Ref # 28012)	28012-0001	2
REFLECTOR-REFLEX (Ref # 28012A)	28012-0002	2
REFLECTOR-REFLEX (Ref # 28012B)	28012-1077	1
BOLT,FLANGED,6X25 (Ref # 92002)	92002-1582	1
SPRING,REAR BRAKE SWITCH (Ref # 92145)	92145-0724	1
BOLT,TORX,6X16 (Ref # 92153)	92153-0967	2
NUT,FLANGED,5MM (Ref # 92210)	92210-0007	1
BOLT-SOCKET,5X12 (Ref # 120)	120CB0512	2
BOLT-FLANGED,6X12 (Ref # 130)	130BA0612	2
NUT-HEX (Ref # 311)	311AB0500	4
WASHER-SPRING,6MM (Ref # 461)	461DA0600	2