


2013 NINJA® 300

PARTS DIAGRAM

Turn Signals

Kawasaki

Let the Good Times Roll®



2013 NINJA® 300

PARTS LIST

Turn Signals

ITEM NAME	PART NUMBER	QUANTITY
SOCKET-ASSY,FR,LH (Ref # 23008)	23008-0139	1
SOCKET-ASSY,FR,RH (Ref # 23008A)	23008-0144	1
LAMP-ASSY-SIGNAL,RR,LH (Ref # 23037)	23037-0247	1
LAMP-ASSY-SIGNAL,RR,RH (Ref # 23037A)	23037-0248	1
LAMP-SIGNAL,FR,LH (Ref # 23040)	23040-0107	1
LAMP-SIGNAL,FR,RH (Ref # 23040A)	23040-0108	1
PAD,10X30X4 (Ref # 39156)	39156-0927	1
SCREW,TAPPING,5X14 (Ref # 92009)	92009-1197	6
BULB,12V 10W (Ref # 92069)	92069-0024	2
BULB,12V 10W (Ref # 92069A)	92069-0058	2
SCREW,2.9X22 (Ref # 92172)	92172-0395	2
WASHER,SIGNAL LAMP (Ref # 92200)	92200-0164	2
WASHER,SIGNAL LAMP (Ref # 92200A)	92200-0165	2
SCREW-PAN-WP-CROS,4X8 (Ref # 224)	224AB0408	2