


1988 Vulcan 88 SE

PARTS DIAGRAM

Air Cleaner

E1130-0242



1988 Vulcan 88 SE

PARTS LIST

Air Cleaner

ITEM NAME	PART NUMBER	QUANTITY
CASE-AIR FILTER,OUTSIDE (Ref # 11011)	11011-1257	2
CASE-AIR FILTER,LH,INSIDE (Ref # 11011A)	11011-1258	1
CASE-AIR FILTER,RH,INSIDE (Ref # 11011B)	11011-1259	1
ELEMENT-AIR FILTER (Ref # 11013)	11013-1122	2
BRACKET,AIR FILTER,LWR (Ref # 11045)	11045-1709	2
BRACKET,AIR FILTER,UPP (Ref # 11046)	11046-1035	2
HOLDER,ELEMENT (Ref # 13091)	13091-1345	2
COVER,AIR FILTER (Ref # 14024)	14024-1681	2
DUCT,SURGE TANK (Ref # 14073)	14073-1297	1
DUCT,FR,CARBURETOR (Ref # 14073A)	14073-1299	1
DUCT,SURGE TANK (Ref # 14073B)	14073-1306	1
DUCT,AIR FILTER (Ref # 14073C)	14073-1310	2
DUCT,INLET (Ref # 14073D)	14073-1319	2
DUCT,RR,CARBURETOR (Ref # 14073E)	14073-1326	1
DUCT,SURGE TANK (Ref # 14073F)	14073-1357	1
VALVE,AIR SWITCH (Ref # 16126)	16126-1188	2
TUBE-ASSY (Ref # 51044)	51044-1089	1
BOLT,6X25 (Ref # 92002)	92002-1137	4
BOLT,6X16 (Ref # 92002A)	92002-1242	8
FITTING (Ref # 92005)	92005-1163	1
SCREW,6X14 (Ref # 92009)	92009-1272	2
CLAMP,TUBE (Ref # 92037)	92037-1076	2
CLAMP,BOOT FITTING (Ref # 92037A)	92037-1112	2
CLAMP,HOSE (Ref # 92037B)	92037-1552	1
CLAMP (Ref # 92037C)	92037-1712	4
CLAMP,14MM (Ref # 92037D)	92037-1862	1
CLAMP,BREATHING TUBE (Ref # 92037E)	92037-192	1
CLAMP,TUBE (Ref # 92037F)	92037-213	4
TUBE,BREATHING (Ref # 92059)	92059-1777	1

1988 Vulcan 88 SE

PARTS LIST

Air Cleaner



ITEM NAME	PART NUMBER	QUANTITY
TUBE,ASV-SURGE TANK (Ref # 92059A)	92059-1779	1
TUBE,VALVE-ASV (Ref # 92059B)	92059-1780	1
TUBE,ASV-CAP(R) (Ref # 92059C)	92059-1783	1
TUBE,4X9X420 (Ref # 92059D)	92059-1820	1
TUBE,4X9X650 (Ref # 92059E)	92059-1846	1
TUBE,AIR FILTER (Ref # 92059F)	92059-1859	1
TUBE,AIR VALVE-AIR FILTER (Ref # 92059G)	92059-1873	1
GROMMET,AIR FILTER (Ref # 92071)	92071-1028	2
SEAL,AIR FILTER (Ref # 92093)	92093-1240	2
BOLT-FLANGED-SMALL,6X10 (Ref # 132)	132J0610	10
SCREW-PAN-CROS (Ref # 220)	220C0430	2