

PARTS DIAGRAM

Left Engine Cover(s)

Let the Good Times Roll®

Exploded view diagram of a mechanical assembly, likely a pump or engine component. The diagram shows the following parts and their assembly relationships:

- Top Section:**
 - 92150:** Main upper housing or cover.
 - 92150C:** Seal or gasket for the upper housing.
 - 92002:** Bolt or screw for the upper housing.
 - 132A:** Flange or mounting plate.
 - 132B:** Bolt or screw for the flange.
 - 132:** Main body or housing.
- Middle Section:**
 - 92043:** Bolt or screw.
 - 92170:** Bolt or screw.
 - 92043A:** Bolt or screw.
 - 11060:** Flange or mounting plate.
 - 14031:** Bolt or screw.
 - 92049:** Bolt or screw.
 - 11060A:** Flange or mounting plate.
- Bottom Section:**
 - 14031A:** Bolt or screw.
 - 670:** Bolt or screw.
 - 11012A:** Bolt or screw.
 - 92049:** Bolt or screw.
 - 671:** Bolt or screw.
 - 11012:** Bolt or screw.
 - 92160A:** Flange or mounting plate.
 - 92160B:** Bolt or screw.
 - 92200:** Bolt or screw.
 - 92151A:** Bolt or screw.
 - 92160:** Flange or mounting plate.
 - 14091A:** Bolt or screw.
 - 13271:** Bolt or screw.
 - 92150B:** Bolt or screw.
 - 92151B:** Bolt or screw.
 - 132D:** Bolt or screw.
 - 14091:** Bolt or screw.
 - 132C:** Bolt or screw.
 - 53044:** Bolt or screw.
 - 92042:** Bolt or screw.
 - 92151:** Bolt or screw.
 - 92160B:** Bolt or screw.
 - 92151A:** Bolt or screw.
 - 92200:** Bolt or screw.
 - 92151A:** Bolt or screw.
 - 92160:** Flange or mounting plate.
 - 92042:** Bolt or screw.

The diagram includes a "FRONT" arrow indicating the orientation of the assembly.

1999 Vulcan 1500 Nomad

PARTS LIST

Left Engine Cover(s)



ITEM NAME	PART NUMBER	QUANTITY
-----------	-------------	----------