


# 2022 KLR® 650

## PARTS DIAGRAM

### Ignition Switch



# 2022 KLR® 650

## PARTS LIST

### Ignition Switch

ITEM NAME	PART NUMBER	QUANTITY
BRACKET,REFLECTOR,FR (Ref # 11045)	11045-1354	1
BRACKET,REFLECTOR,FR (Ref # 11054)	11054-1889	1
BRACKET,REAR BRAKE (Ref # 11057)	11057-4313	1
BRACKET,REFLECTOR,RR (Ref # 11057A)	11057-4368	1
COVER,SIDE STAND SWITCH (Ref # 14091)	14091-1553	1
SWITCH-ASSY-IGNITION (Ref # 27005)	27005-0702	1
SWITCH-ASSY-IGNITION (Ref # 27005A)	27005-5190	1
KEY-LOCK,BLANK (Ref # 27008)	27008-0688	1
SWITCH,SIDE STAND (Ref # 27010)	27010-0118	1
SWITCH,REAR BRAKE (Ref # 27010A)	27010-0969	1
LOCK-ASSY,TOOL COVER (Ref # 27016)	27016-5419	1
LOCK-ASSY,TANK CAP (Ref # 27016A)	27016-5421	1
LOCK-ASSY,PANNIER (Ref # 27016B)	27016-5422	2
REFLECTOR-REFLEX (Ref # 28012)	28012-1003	2
REFLECTOR-REFLEX (Ref # 28012A)	28012-1077	1
REFLECTOR-REFLEX (Ref # 28012B)	28012-1088	2
GUARD,50X30 (Ref # 55020)	55020-2334	1
GUARD,REAR BRAKE (Ref # 55020A)	55020-2378	1
BOLT,6X12 (Ref # 92002)	92002-1132	2
BOLT,FLANGED,6X25 (Ref # 92002A)	92002-1582	1
NUT,FLANGED,6MM,BLACK (Ref # 92015)	92015-1233	2
NUT,FLANGED,6MM (Ref # 92015A)	92015-1367	2
WASHER,6.2X15X1.2 (Ref # 92022)	92022-2373	1
COLLAR (Ref # 92143)	92143-1331	1
SPRING,REAR BRAKE (Ref # 92145)	92145-1896	1
COLLAR,6.15X10.15X6 (Ref # 92152)	92152-1535	2
BOLT,TORX,6X22 (Ref # 92154)	92154-1858	2
BOLT,SOCKET,6X10 (Ref # 92154A)	92154-2558	1
BOLT,FLANGED,5X12 (Ref # 92154B)	92154-2893	1

# 2022 KLR® 650

## PARTS LIST

### Ignition Switch

ITEM NAME	PART NUMBER	QUANTITY
CLAMP (Ref # 92171)	92171-0640	2
NUT,FLANGED,5MM (Ref # 92210)	92210-0007	3
NUT-HEX,5MM (Ref # 311)	311AB0500	2
WASHER-SPRING,6MM (Ref # 461)	461DA0600	2
WASHER-SPRING,5MM (Ref # 461A)	461DB0500	2