


2010 Jet Ski® Ultra® 260X

PARTS DIAGRAM Electrical Equipment



2010 Jet Ski® Ultra® 260X

PARTS LIST

Electrical Equipment

| ITEM NAME | PART NUMBER | QUANTITY |
|--|-------------|----------|
| CAP (Ref # 11012) | 11012-3004 | 2 |
| CAP,LEAD WIRE (Ref # 11012A) | 11012-3726 | 2 |
| CAP,TERMINAL (Ref # 11065) | 11065-3729 | 1 |
| CAP,TERMINAL (Ref # 11065A) | 11065-3732 | 1 |
| FLOAT,KEY (Ref # 16031) | 16031-3991 | 1 |
| SENSOR,MAGNET (Ref # 21176) | 21176-3746 | 1 |
| SENSOR,HOLE IC (Ref # 21176A) | 21176-3748 | 1 |
| WIRE-LEAD,BATTERY(-)-STARTER (Ref # 26011) | 26011-3915 | 1 |
| WIRE-LEAD,RELAY-STARTER (Ref # 26011A) | 26011-3916 | 1 |
| WIRE-LEAD,RELAY-BATTERY(+) (Ref # 26011B) | 26011-3924 | 1 |
| BATTERY,YTX20L-BS,12V 18AH (Ref # 26012) | 26012-3730 | 1 |
| FPO MODE KEY (Ref # 27008) | 27008-3767 | 1 |
| SLO MODE KEY (Ref # 27008A) | 27008-3768 | 1 |
| SWITCH-ASSY (Ref # 27045) | 27045-3755 | 1 |
| CASE-BATTERY (Ref # 32097) | 32097-3709 | 1 |
| BOLT,6X30 (Ref # 92002) | 92002-3726 | 4 |
| SCREW,5X16 (Ref # 92009) | 92009-3868 | 3 |
| NUT,CLIP,5MM (Ref # 92015) | 92015-3830 | 2 |
| GROMMET (Ref # 92071) | 92071-3826 | 1 |
| GROMMET (Ref # 92071A) | 92071-3840 | 1 |
| BAND,340X22 (Ref # 92072) | 92072-3805 | 2 |
| BAND,L=100.08 (Ref # 92072A) | 92072-3882 | 1 |
| DAMPER,BATTERY CASE (Ref # 92161) | 92161-3762 | 1 |
| BOLT-SOCKET,5X16 (Ref # 120) | 120R0516 | 2 |
| W-PLAIN-S,5MM (Ref # 410) | 410S0500 | 2 |