


# 2008 Vulcan® 2000

## PARTS DIAGRAM

### Ignition Switch/Locks/Reflectors



# 2008 Vulcan® 2000

## PARTS LIST

### Ignition Switch/Locks/Reflectors

ITEM NAME	PART NUMBER	QUANTITY
BOLT-FLANGED,6X12 (Ref # 130)	130BB0612	2
BOLT-FLANGED,6X16 (Ref # 130A)	130BB0616	6
BOLT-FLANGED,6X25 (Ref # 130B)	130BB0625	2
BRACKET,IGNITION SWITCH (Ref # 11053)	11053-0218	1
BRACKET,REFLECTOR,RR,LH (Ref # 11053A)	11053-0222	1
BRACKET,REFLECTOR,RR,RH (Ref # 11053B)	11053-0223	1
BRACKET,SIDE COVER LOCK (Ref # 11053C)	11053-0920	1
ROTOR,LOCK,TANK CAP (Ref # 21007)	21007-5053	1
SWITCH-ASSY-IGNITION (Ref # 27005)	27005-0004	1
KEY-LOCK,BLANK (Ref # 27008)	27008-1211	1
SWITCH,SIDE STAND (Ref # 27010)	27010-0011	1
SWITCH,REAR BRAKE (Ref # 27010A)	27010-0023	1
LOCK-ASSY,SEAT STRIKER (Ref # 27016)	27016-1115	1
LOCK-ASSY,LID (Ref # 27016A)	27016-5279	1
LOCK-ASSY,STEERING (Ref # 27016B)	27016-5298	1
LOCK-ASSY,HELMET (Ref # 27016C)	27016-5311	1
SWITCH-ASSY (Ref # 27045)	27045-5212	1
REFLECTOR-REFLEX,FR (Ref # 28012)	28012-1009	2
REFLECTOR-REFLEX (Ref # 28012A)	28012-1088	2
BRACKET-SEAT (Ref # 32046)	32046-0037	1
SCREW,5X14 (Ref # 92009)	92009-1341	1
SPACER,IGNITION SWITCH (Ref # 92026)	92026-0018	1
COLLAR,L=15.6 (Ref # 92143)	92143-1041	2
SPRING,REAR BRAKE SWITCH (Ref # 92144)	92144-1141	1
BOLT,SOCKET,6X40 (Ref # 92150)	92150-1958	1
BOLT,SOCKET,6X12 (Ref # 92151)	92151-1219	2
BOLT,TORX,8X22 (Ref # 92153)	92153-1273	2
DAMPER (Ref # 92160)	92160-1167	2
NUT,FLANGED,5MM (Ref # 92210)	92210-0007	4