

Muffler(s)

Let the Good Times Roll®

Exploded view diagram of a vehicle's front suspension and steering components. The diagram shows the following parts and their assembly relationships:

- Front View:** Indicated by an arrow pointing left.
- Upper Control Arm Assembly:**
 - Part 18049 (Upper Control Arm) connects to the frame via bushings 11060 and 18069.
 - Part 14024 (Upper Control Arm Bracket) is attached to the upper control arm.
 - Part 92015 (Upper Control Arm Nut) secures the upper control arm.
- Lower Control Arm Assembly:**
 - Part 18049A (Lower Control Arm) connects to the frame via bushings 11060 and 18069.
 - Part 14024A (Lower Control Arm Bracket) is attached to the lower control arm.
 - Part 92015 (Lower Control Arm Nut) secures the lower control arm.
- Steering Knuckle Assembly:**
 - Part 49106 (Steering Knuckle) is connected to the lower control arm via a ball joint (223).
 - Part 92037 (Steering Knuckle Nut) secures the steering knuckle.
 - Part 92037A (Steering Knuckle Nut) is shown as an alternative or additional component.
- Ball Joint Assembly:**
 - Part 223 (Ball Joint) connects the steering knuckle to the control arm.
- Other Components:**
 - Part 18002 (Lower Control Arm) is shown at the bottom.
 - Part 18002A (Lower Control Arm) is shown on the right.
 - Part 18004 (Lower Control Arm) is shown on the left.
 - Part 11009 (Lower Control Arm) is shown on the left.
 - Part 92075 (Lower Control Arm) is shown on the left.
 - Part 92170 (Lower Control Arm) is shown on the left.
 - Part 92022 (Lower Control Arm) is shown on the right.
 - Part 92028 (Lower Control Arm) is shown on the right.
 - Part 132 (Lower Control Arm) is shown on the right.
 - Part 92015A (Lower Control Arm Nut) is shown on the right.

1998 Vulcan 750

PARTS LIST

Muffler(s)

ITEM NAME	PART NUMBER	QUANTITY
BOLT-FLANGED-SMALL (Ref # 132)	132E0840	4
SCREW-PAN-WS-CROS (Ref # 223)	223X0620	5
GASKET,EXHAUST PIPE CONNECTING (Ref # 11009)	11009-1666	4
GASKET,EXHAUST PIPE (Ref # 11060)	11060-1119	2
COVER,FR (Ref # 14024)	14024-1091	1
COVER,RR (Ref # 14024A)	14024-1092	1
BODY-COMP-MUFFLER,LH (Ref # 18002)	18002-1701	1
BODY-COMP-MUFFLER,RH (Ref # 18002A)	18002-1702	1
CHAMBER-PREMUFFLER (Ref # 18004)	18004-1055	1
PIPE-EXHAUST,FR (Ref # 18049)	18049-1373	1
PIPE-EXHAUST,RR (Ref # 18049A)	18049-1374	1
HOLDER-EXHAUST PIPE (Ref # 18069)	18069-1061	4
COVER-MUFFLER,LH (Ref # 49106)	49106-1053	1
COVER-MUFFLER,RH (Ref # 49106A)	49106-1054	1
NUT,CAP,8MM (Ref # 92015)	92015-1371	4
NUT,FLANGED,8MM (Ref # 92015A)	92015-1933	2
WASHER,CAP TYPE (Ref # 92022)	92022-1638	4
BUSHING,MUFFLER (Ref # 92028)	92028-1746	8
CLAMP,EXHAUST PIPE COVER (Ref # 92037)	92037-1613	3
CLAMP,MUFFLER COVER (Ref # 92037A)	92037-1615	2
DAMPER (Ref # 92075)	92075-005	1
CLAMP,52MM (Ref # 92170)	92170-1446	4