

Clutch

Let the Good Times Roll®

Exploded view diagram of a transmission assembly. The diagram shows the following components and their part numbers:

- 11044**: Input shaft assembly.
- 13116**: Input shaft seal.
- 13116A**: Input shaft.
- 670**: Input shaft nut.
- 92066**: Input shaft lock washer.
- 130**: Input shaft lock pin.
- 13236**: Input shaft lock pin clip.
- Ref. Front Bevel Gear**: Reference to the front bevel gear.
- 92028**: Output shaft seal.
- 92046**: Output shaft nut.
- 92026A**: Output shaft lock washer.
- 13087**: Front output shaft gear.
- 13088**: Intermediate output shaft gear.
- 13089**: Intermediate output shaft gear.
- 13095**: Intermediate output shaft gear.
- 92026**: Intermediate output shaft seal.
- 13187**: Rear output shaft gear.
- 92081**: Rear output shaft nut.
- 92001**: Rear output shaft lock pin.
- 13091**: Rear output shaft lock pin.
- 92045**: Rear output shaft lock pin clip.
- 92015**: Rear output shaft lock pin.
- 92022**: Rear output shaft lock pin clip.

1990 Vulcan 750

PARTS LIST

Clutch



ITEM NAME	PART NUMBER	QUANTITY
-----------	-------------	----------