



# 2008 Vulcan® 2000 Classic LT

## PARTS DIAGRAM

### Valve(s)

E1210



# 2008 Vulcan® 2000 Classic LT

## PARTS LIST

### Valve(s)

| ITEM NAME                              | PART NUMBER | QUANTITY |
|--|-------------|----------|
| VALVE-INTAKE (Ref # 12004)             | 12004-0001  | 4        |
| VALVE-EXHAUST (Ref # 12005)            | 12005-0001  | 4        |
| RETAINER-VALVE SPRING (Ref # 12009)    | 12009-0002  | 8        |
| COLLET (Ref # 12011)                   | 12011-0001  | 16       |
| ARM-ROCKER (Ref # 12016)               | 12016-0015  | 2        |
| ARM-ROCKER (Ref # 12016A)              | 12016-0016  | 2        |
| SHAFT-ROCKER,EXHAUST (Ref # 12020)     | 12020-0001  | 2        |
| SHAFT-ROCKER,INTAKE (Ref # 12020A)     | 12020-0002  | 2        |
| ADJUSTER-LASH (Ref # 12025)            | 12025-1053  | 8        |
| SEAT-SPRING (Ref # 16007)              | 16007-0001  | 8        |
| SPRING-ENGINE VALVE (Ref # 49078)      | 49078-0001  | 8        |
| SEAL-OIL,RVC2 6 10.5 9.4 (Ref # 92049) | 92049-0009  | 8        |
| BOLT,6X38 (Ref # 92150)                | 92150-1301  | 12       |