


2008 Vulcan® 2000 Classic LT

PARTS DIAGRAM

Cowling



2008 Vulcan® 2000 Classic LT

PARTS LIST

Cowling

ITEM NAME	PART NUMBER	QUANTITY
BRACKET,MAIN (Ref # 11054)	11054-0576	1
PLATE,WINDSHIELD,LH,OUTER (Ref # 13271)	13271-0704	1
PLATE,WINDSHIELD,RH,OUTER (Ref # 13271A)	13271-0705	1
PLATE,WINDSHIELD,CNT,OUTER (Ref # 13271B)	13271-0706	1
PLATE,WINDSHIELD,CNT,INNER (Ref # 13271C)	13271-0707	1
PLATE,WINDSHIELD STAY (Ref # 13271D)	13271-0826	2
STAY,WINDSHIELD,LH (Ref # 35063)	35063-0257	1
STAY,WINDSHIELD,RH (Ref # 35063A)	35063-0258	1
WINDSHIELD (Ref # 39154)	39154-0017	1
BOLT,SOCKET,6X16 (Ref # 92151)	92151-1751	8
BOLT,SOCKET,8X16 (Ref # 92151A)	92151-1752	2
COLLAR,10X18X18 (Ref # 92152)	92152-0394	2
COLLAR (Ref # 92152A)	92152-0395	2
BOLT,SOCKET,8X35 (Ref # 92153)	92153-1469	2
BOLT,SOCKET,8X48 (Ref # 92153A)	92153-1470	2
DAMPER,WINDSHIELD,CNT (Ref # 92161)	92161-0330	2
DAMPER,WINDSHIELD,LH&RH,OUTER (Ref # 92161A)	92161-0332	2
DAMPER,WINDSHIELD,LH&RH,INNER (Ref # 92161B)	92161-0382	2
WASHER,6.5X14.5X1.5 (Ref # 92200)	92200-3775	8
NUT,CAP,8MM (Ref # 92210)	92210-1132	2
NUT,CAP,6MM (Ref # 92210A)	92210-1252	8