


# 2022 JET SKI® ULTRA® 310LX

## PARTS DIAGRAM

### Electrical Equipment



# 2022 JET SKI® ULTRA® 310LX

## PARTS LIST

### Electrical Equipment

| ITEM NAME                                 | PART NUMBER | QUANTITY |
|-------------------------------------------|-------------|----------|
| CAP (Ref # 11012)                         | 11012-3004  | 2        |
| CAP (Ref # 11065)                         | 11065-3716  | 2        |
| CAP,TERMINAL (Ref # 11065A)               | 11065-3729  | 1        |
| CAP,TERMINAL (Ref # 11065B)               | 11065-3732  | 1        |
| SENSOR,MAGNET (Ref # 21176)               | 21176-3746  | 1        |
| SENSOR,HOLE IC (Ref # 21176A)             | 21176-3748  | 1        |
| WIRE-LEAD,RELAY-STARTER (Ref # 26011)     | 26011-0723  | 1        |
| WIRE-LEAD,BATTERY(-) (Ref # 26011A)       | 26011-0835  | 1        |
| WIRE-LEAD,RELAY-BATTERY(+) (Ref # 26011B) | 26011-1997  | 1        |
| BATTERY,YTX20L-BS,12V 18AH (Ref # 26012)  | 26012-0787  | 1        |
| FPO MODE KEY (Ref # 27008)                | 27008-0684  | 1        |
| SLO MODE KEY (Ref # 27008A)               | 27008-0685  | 1        |
| SWITCH-ASSY (Ref # 27048)                 | 27048-0056  | 1        |
| CASE-BATTERY (Ref # 32097)                | 32097-3709  | 1        |
| SCREW,5X16 (Ref # 92009)                  | 92009-3868  | 3        |
| NUT,CLIP,5MM (Ref # 92015)                | 92015-3830  | 2        |
| GROMMET,31.5X50X11 (Ref # 92071)          | 92071-0737  | 2        |
| BAND,340X22 (Ref # 92072)                 | 92072-3805  | 4        |
| BAND,L=100.08 (Ref # 92072A)              | 92072-3882  | 1        |
| DAMPER,BATTERY CASE (Ref # 92161)         | 92161-1388  | 1        |
| BOLT NUT KIT (Ref # 99999)                | 99999-0311  | 1        |
| BOLT-SOCKET,5X16 (Ref # 120)              | 120R0516    | 2        |
| BOLT-WP,6X35 (Ref # 156)                  | 156R0635    | 4        |
| W-PLAIN-S,5MM (Ref # 410)                 | 410S0500    | 2        |