

Valve(s)

Let the Good Times Roll®

Exploded view diagram of a vehicle chassis assembly, showing various components and their part numbers. The diagram includes a "FRONT" arrow pointing left.

Key components and part numbers shown:

- 92009, 92015, 12011, 12009, 49078, 49078A, 16007, 16007A, 92049, 12005, 12011, 12009, 49078, 49078A, 16007, 16007A, 92049, 12004
- 92081, 12016, 670, 551, 92066, 12020
- 12016, 92066A, 670, 551, 12020

1997 Eliminator 600

PARTS LIST

Valve(s)

ITEM NAME	PART NUMBER	QUANTITY
VALVE-INTAKE (Ref # 12004)	12004-1114	8
VALVE-EXHAUST (Ref # 12005)	12005-1062	8
RETAINER-VALVE SPRING (Ref # 12009)	12009-1060	16
COLLET (Ref # 12011)	12011-1051	32
ARM-ROCKER (Ref # 12016)	12016-1062	8
SHAFT-ROCKER (Ref # 12020)	12020-1058	4
SEAT-SPRING,12.1X16.2X0.5 (Ref # 16007)	16007-1177	16
SEAT-SPRING,17.5X23.8X0.5 (Ref # 16007A)	16007-1178	16
SPRING-ENGINE VALVE,OUTER (Ref # 49078)	49078-1060	16
SPRING-ENGINE VALVE,INNER (Ref # 49078A)	49078-1061	16
SCREW,VALVE ADJUST (Ref # 92009)	92009-1109	16
NUT,5MM (Ref # 92015)	92015-1529	16
SEAL-OIL,VSB58.558 (Ref # 92049)	92049-1218	16
PLUG,14X11.5 (Ref # 92066)	92066-1192	2
PLUG (Ref # 92066A)	92066-1257	2
SPRING,ROCKER ARM (Ref # 92081)	92081-1636	8
PIN-DOWEL (Ref # 551)	551A0540	4
O RING,15MM (Ref # 670)	670B2015	4