

2021 NINJA® 400


PARTS DIAGRAM

Turn Signals

Kawasaki

Let the Good Times Roll®

F2730



2021 NINJA® 400

PARTS LIST

Turn Signals

ITEM NAME	PART NUMBER	QUANTITY
BRACKET (Ref # 11057)	11057-1614	1
LENS-COMP (Ref # 23007)	23007-0228	1
LENS-COMP (Ref # 23007A)	23007-0229	1
SOCKET-ASSY,BLACK (Ref # 23008)	23008-0191	1
SOCKET-ASSY,GRAY (Ref # 23008A)	23008-0192	1
LAMP-ASSY-SIGNAL,RR RH (Ref # 23037)	23037-0430	1
LAMP-ASSY-SIGNAL,RR LH (Ref # 23037A)	23037-0431	1
LAMP-SIGNAL,FR LH (Ref # 23040)	23040-0153	1
LAMP-SIGNAL,FR RH (Ref # 23040A)	23040-0154	1
PAD,FR SIGNAL LAMP,RH (Ref # 39156)	39156-2187	1
PAD,10X140X10 (Ref # 39156A)	39156-2360	2
PAD,10X80X10 (Ref # 39156B)	39156-2381	1
PAD,87X236X10 (Ref # 39156C)	39156-2382	1
BULB,12V 10W (Ref # 92069)	92069-0058	2
BULB,12V 10W (Ref # 92069A)	92069-0090	2
SCREW,5X12 (Ref # 92172)	92172-0821	6
SCREW,4X14 (Ref # 92172A)	92172-1117	2
WASHER (Ref # 92200)	92200-0855	2
WASHER,NUT,4MM (Ref # 92200A)	92200-2222	2
SCREW-PAN-WP-CROS,4X8 (Ref # 224)	224AB0408	2