


PARTS DIAGRAM

Front Fork



PARTS LIST

Front Fork

ITEM NAME	PART NUMBER	QUANTITY
CAP,FORK (Ref # 11065)	11065-1372	1
CAP,FORK (Ref # 11065A)	11065-1410	1
ROD-PUSH (Ref # 13116)	13116-0753	1
GUIDE-COMP (Ref # 13235)	13235-0015	1
SEAT-SPRING (Ref # 16007)	16007-0780	1
STOPPER (Ref # 32085)	32085-0883	1
STOPPER (Ref # 32085A)	32085-0884	1
PIPE-FORK OUTER (Ref # 44008)	44008-0092	2
PIPE-FORK INNER,LH (Ref # 44013)	44013-0401	1
PIPE-FORK INNER,RH (Ref # 44013A)	44013-0405	1
CYLINDER-SET-FORK,RH (Ref # 44023)	44023-0184	1
CYLINDER-SET-FORK,LH (Ref # 44023A)	44023-0191	1
SPRING-FRONT FORK (Ref # 44026)	44026-0265	1
SPRING-FRONT FORK (Ref # 44026A)	44026-0291	1
SPRING-FRONT FORK (Ref # 44026B)	44026-0293	1
HOLDER-FORK UNDER (Ref # 44037)	44037-0194	1
HOLDER-FORK UPPER (Ref # 44039)	44039-0196	1
BUSHING-FRONT FORK (Ref # 44065)	44065-0069	2
BUSHING-FRONT FORK (Ref # 44065A)	44065-0070	2
DAMPER-ASSY,FORK,LH (Ref # 44071)	44071-1577	1
DAMPER-ASSY,FORK,RH (Ref # 44071A)	44071-1590	1
SPACER (Ref # 92026)	92026-0905	2
RING-SNAP (Ref # 92033)	92033-0829	2
RING-SNAP (Ref # 92033A)	92033-0830	1
RING-SNAP (Ref # 92033B)	92033-1286	1
SEAL-OIL (Ref # 92049)	92049-0870	2
RING-O (Ref # 92055)	92055-0994	2
PLUG (Ref # 92066)	92066-0032	1
SEAL,FORK OUTER (Ref # 92093)	92093-0789	2

PARTS LIST

Front Fork

ITEM NAME	PART NUMBER	QUANTITY
BOLT,SOCKET,8X30 (Ref # 92153)	92153-0500	2
BOLT,SOCKET,8X35 (Ref # 92153A)	92153-0854	4
BOLT (Ref # 92154)	92154-4220	1
DAMPER (Ref # 92161)	92161-2369	2
NUT (Ref # 92210)	92210-1839	2