

Transmission

Let the Good Times Roll®

Exploded view diagram of a mechanical assembly, likely a transmission or gearbox, showing various components and their assembly sequence. The diagram includes a "FRONT" arrow pointing left.

Key components and part numbers shown:

- Input Shaft Assembly:** 13127 (Input Shaft), 13128 (Intermediate Shaft), 13139 (Output Shaft), 13144 (Input Gear), 13145 (Intermediate Gear), 13146 (Output Gear).
- Gears:** 13260 (Input Gear), 13260A (Intermediate Gear), 13260B (Output Gear), 13260C (Input Gear), 13260D (Intermediate Gear), 13260E (Output Gear), 13260F (Input Gear), 13260G (Intermediate Gear), 13260H (Output Gear).
- Shafts and Hubs:** 92033 (Input Shaft Hub), 92034 (Intermediate Shaft Hub), 92035 (Output Shaft Hub), 92036 (Input Shaft Hub), 92037 (Intermediate Shaft Hub), 92038 (Output Shaft Hub), 92039 (Input Shaft Hub), 92040 (Intermediate Shaft Hub), 92041 (Output Shaft Hub), 92042 (Input Shaft Hub), 92043 (Intermediate Shaft Hub), 92044 (Output Shaft Hub), 92045 (Input Shaft Hub), 92046 (Intermediate Shaft Hub), 92047 (Output Shaft Hub), 92048 (Input Shaft Hub), 92049 (Intermediate Shaft Hub), 92050 (Output Shaft Hub).
- Clutch and Flywheel:** 92051 (Clutch), 92052 (Flywheel), 92053 (Clutch), 92054 (Flywheel), 92055 (Clutch), 92056 (Flywheel), 92057 (Clutch), 92058 (Flywheel), 92059 (Clutch), 92060 (Flywheel), 92061 (Clutch), 92062 (Flywheel), 92063 (Clutch), 92064 (Flywheel), 92065 (Clutch), 92066 (Flywheel), 92067 (Clutch), 92068 (Flywheel), 92069 (Clutch), 92070 (Flywheel), 92071 (Clutch), 92072 (Flywheel), 92073 (Clutch), 92074 (Flywheel), 92075 (Clutch), 92076 (Flywheel), 92077 (Clutch), 92078 (Flywheel), 92079 (Clutch), 92080 (Flywheel), 92081 (Clutch), 92082 (Flywheel), 92083 (Clutch), 92084 (Flywheel), 92085 (Clutch), 92086 (Flywheel), 92087 (Clutch), 92088 (Flywheel), 92089 (Clutch), 92090 (Flywheel), 92091 (Clutch), 92092 (Flywheel), 92093 (Clutch), 92094 (Flywheel), 92095 (Clutch), 92096 (Flywheel), 92097 (Clutch), 92098 (Flywheel), 92099 (Clutch), 92100 (Flywheel).
- Other Components:** 480 (Bushing), 480A (Bushing), 480B (Bushing), 480C (Bushing), 480D (Bushing), 480E (Bushing), 480F (Bushing), 480G (Bushing), 480H (Bushing), 480I (Bushing), 480J (Bushing), 480K (Bushing), 480L (Bushing), 480M (Bushing), 480N (Bushing), 480O (Bushing), 480P (Bushing), 480Q (Bushing), 480R (Bushing), 480S (Bushing), 480T (Bushing), 480U (Bushing), 480V (Bushing), 480W (Bushing), 480X (Bushing), 480Y (Bushing), 480Z (Bushing).

2000 ZRX1100

PARTS LIST

Transmission

ITEM NAME	PART NUMBER	QUANTITY
CIRCLIP-TYPE-C,28MM (Ref # 480)	480J2800	2
CIRCLIP (Ref # 480A)	480J2900	1
BALL-STEEL,5/32" (Ref # 600)	600A0500	3
SHAFT-TRANSMISSION INPUT,15T (Ref # 13127)	13127-1257	1
SHAFT-TRANSMISSION OUTPUT (Ref # 13128)	13128-1218	1
SHIFTER (Ref # 13139)	13139-1079	1
SPROCKET-OUTPUT,17T (Ref # 13144)	13144-1283	1
GEAR,INPUT TOP,28T (Ref # 13260)	13260-1500	1
GEAR,INPUT 2ND,19T (Ref # 13260A)	13260-1663	1
GEAR,INPUT 3RD&4TH,23T&26T (Ref # 13260B)	13260-1664	1
GEAR,OUTPUT LOW,41T (Ref # 13260C)	13260-1665	1
GEAR,OUTPUT 2ND,37T (Ref # 13260D)	13260-1666	1
GEAR,OUTPUT 3RD,34T (Ref # 13260E)	13260-1667	1
GEAR,OUTPUT 4TH,31T (Ref # 13260F)	13260-1668	1
GEAR,OUTPUT TOP,29T (Ref # 13260G)	13260-1669	1
NUT,20MM (Ref # 92015)	92015-1210	1
WASHER,28.3X42X2.9 (Ref # 92022)	92022-1219	1
WASHER,22.3X35X1.6 (Ref # 92022A)	92022-212	2
BUSHING,OUTPUT,3RD&4TH (Ref # 92028)	92028-1753	1
BUSHING,INPUT,TOP GEAR (Ref # 92028A)	92028-1802	1
RING-SNAP,20X25.5X1.2 (Ref # 92033)	92033-025	2
BEARING-BALL (Ref # 92045)	92045-1186	2
BEARING-NEEDLE,FWF-223014 (Ref # 92046)	92046-031	2
RACE,INPUT SHAFT (Ref # 92048)	92048-1052	1
RACE,30X38X15 (Ref # 92048A)	92048-1053	1
COLLAR,28X40X33.5 (Ref # 92143)	92143-1731	1
WASHER,TOOTHED,23.9X45X1.0 (Ref # 92200)	92200-1234	1
WASHER,TOOTHED,28X30X2 (Ref # 92200A)	92200-1277	1
WASHER,29.9X40X1.5 (Ref # 92200B)	92200-1278	1

2000 ZRX1100

PARTS LIST

Transmission



ITEM NAME	PART NUMBER	QUANTITY
WASHER (Ref # 92200C)	92200-1340	1