

2010 Z750 (European)


PARTS DIAGRAM

Ignition Switch

Kawasaki

Let the Good Times Roll®

F2770



2010 Z750 (European)

PARTS LIST

Ignition Switch

ITEM NAME	PART NUMBER	QUANTITY
BOLT-SOCKET,5X16 (Ref # 120)	120CA0516	2
BOLT-SOCKET,5X10 (Ref # 120A)	120CB0510	1
BOLT-SOCKET,5X12 (Ref # 120B)	120CB0512	2
BOLT-FLANGED,6X12 (Ref # 130)	130BB0612	6
BRACKET,SEAT LOCK (Ref # 11054)	11054-0510	1
BRACKET,IMMOBI AMP. (Ref # 11054A)	11054-1182	1
ROTOR,LOCK,TANK CAP (Ref # 21007)	21007-5056	1
AMPLIFIER,IMMOBI (Ref # 21181A)	21181-0004	1
ANTENNA,IMMOBI (Ref # 21183)	21183-0002	1
SWITCH-ASSY-IGNITION (Ref # 27005)	27005-5138	1
KEY-LOCK,BLANK,IMMOBI,SUB (Ref # 27008)	27008-0029	1
MASTER KEY SET(BLANK),IMMOBI (Ref # 27008C)	27008-5052	1
SWITCH,SIDE STAND (Ref # 27010)	27010-0065	1
SWITCH,REAR BRAKE (Ref # 27010A)	27010-1479	1
SPRING,BRAKE LAMP SWITCH (Ref # 27011)	27011-021	1
LOCK-ASSY,SEAT STRIKER (Ref # 27016)	27016-1115	3
LOCK-ASSY,SEAT (Ref # 27016A)	27016-5310	1
SWITCH-ASSY (Ref # 27045)	27045-5338	1
REFLECTOR-REFLEX (Ref # 28012)	28012-1077	1
MARK,IMMOBI (Ref # 56052)	56052-0292	1
NUT,WELL,5MM (Ref # 92015)	92015-1757	2
BOLT,TORX,6X22 (Ref # 92151)	92151-1946	2
BOLT,6X35 (Ref # 92151A)	92151-1982	1
COLLAR (Ref # 92152)	92152-0352	2
DAMPER,IGNITION SWITCH (Ref # 92161)	92161-0240	4
DAMPER,IGNITION SWITCH (Ref # 92161A)	92161-0257	1
SCREW,4X8 (Ref # 92172)	92172-0188	2
WASHER,6X20X1.6 (Ref # 92200)	92200-0212	2
NUT,FLANGED,5MM (Ref # 92210)	92210-0007	1