

Generator

Let the Good Times Roll®

Exploded view diagram of a vehicle headlight assembly. The diagram shows the following components and their assembly relationships:

- 92002B**: A long screw used to secure the top of the headlight housing.
- 21001**: A bracket or support piece located at the top of the assembly.
- 92002C**: A small screw used for internal mounting.
- 92049**: A small circular component, possibly a seal or washer.
- 92055**: A small circular component, possibly a seal or washer.
- 13227**: A small circular component, possibly a seal or washer.
- 92055A**: A lens or protective cover for the headlight.
- 92045A**: A circular component, possibly a seal or washer.
- 13091**: A small circular component, possibly a seal or washer.
- 14014**: A circular component, possibly a seal or washer.
- 92004**: A long screw used for internal mounting.
- 13091B**: A small circular component, possibly a seal or washer.
- 92045**: A small circular component, possibly a seal or washer.
- 13091A**: A small circular component, possibly a seal or washer.
- 21007**: A complex internal component, possibly a reflector or mounting bracket.
- 92002A**: A long screw used for internal mounting.
- 21066**: A complex internal component, possibly a reflector or mounting bracket.
- 13091C**: A small circular component, possibly a seal or washer.
- 21039**: A small rectangular component, possibly a bracket or support.
- 92081**: A small circular component, possibly a seal or washer.
- 16146**: A large, curved component, possibly a reflector or housing part.
- 92002**: A long screw used for internal mounting.
- 92002A**: A long screw used for internal mounting.
- 92002**: A long screw used for internal mounting.
- 92002A**: A long screw used for internal mounting.
- 92015**: A small circular component, possibly a seal or washer.
- 14025**: A complex internal component, possibly a reflector or mounting bracket.
- 16073**: A complex internal component, possibly a reflector or mounting bracket.
- 13091D**: A small circular component, possibly a seal or washer.
- 26011**: A wiring harness with a connector labeled **A** and a terminal labeled **B**.

1995 GPZ 1100

PARTS LIST

Generator

ITEM NAME	PART NUMBER	QUANTITY
HOLDER,BEARING (Ref # 13091)	13091-1326	1
HOLDER,COVER (Ref # 13091A)	13091-1327	1
HOLDER,BEARING (Ref # 13091B)	13091-1328	1
HOLDER,BRUSH (Ref # 13091C)	13091-1465	1
RECTIFIER (Ref # 13091D)	13091-1466	1
HOUSING,GENERATOR (Ref # 13227)	13227-1079	1
PLATE-POSITION (Ref # 14014)	14014-1065	1
COVER,RECTIFIER (Ref # 14025)	14025-1942	1
INSULATOR (Ref # 16073)	16073-1062	1
COVER-ASSY,GENERATOR (Ref # 16146)	16146-1163	1
GENERATOR (Ref # 21001)	21001-1134	1
ROTOR,GENERATOR (Ref # 21007)	21007-1196	1
BRUSH,CARBON (Ref # 21039)	21039-1052	2
REGULATOR-VOLTAGE (Ref # 21066)	21066-1076	1
WIRE-LEAD,GENERATOR (Ref # 26011)	26011-1619	1
SCREW,4X8 (Ref # 92002)	92002-1379	2
SCREW,5X17.5 (Ref # 92002A)	92002-1380	3
BOLT,SOCKET,8X45 (Ref # 92002B)	92002-1716	3
BOLT (Ref # 92002C)	92002-1856	3
STUD (Ref # 92004)	92004-1196	3
NUT (Ref # 92015)	92015-1800	3
BEARING-BALL,#6002NC (Ref # 92045)	92045-1133	1
BEARING-BALL,#6002 (Ref # 92045A)	92045-1185	1
SEAL-OIL (Ref # 92049)	92049-1200	1
RING-O,3.5MM (Ref # 92055)	92055-1264	3
RING-O,70.6X2.4 (Ref # 92055A)	92055-1366	1
SPRING,BRUSH (Ref # 92081)	92081-1759	2