

Generator

Let the Good Times Roll®

Exploded view diagram of a vehicle's front suspension and steering assembly. The diagram shows the following components and their assembly order:

- 13227**: Upper control arm assembly.
- 14014**: Lower control arm assembly.
- 92009**: Lower control arm ball joint.
- 92045**: Lower control arm bushing.
- 13091A**: Lower control arm bushing.
- 92015**: Lower control arm nut.
- 92049**: Lower control arm nut.
- 92055**: Lower control arm nut.
- 21001**: Lower control arm nut.
- 21007**: Lower control arm nut.
- 31011**: Lower control arm nut.
- 92153**: Lower control arm nut.
- 92004**: Lower control arm nut.
- 92004**: Lower control arm nut.
- 92004**: Lower control arm nut.
- 92093A**: Lower control arm nut.
- 13280**: Lower control arm nut.
- 92093**: Lower control arm nut.
- 92093A**: Lower control arm nut.
- 92093A**: Lower control arm nut.
- 92015A**: Lower control arm nut.
- 26011**: Lower control arm nut.
- 92072**: Lower control arm nut.
- 16146**: Lower control arm nut.
- 92153C**: Lower control arm nut.
- 92153C**: Lower control arm nut.
- 92153C**: Lower control arm nut.
- 92153A**: Lower control arm nut.
- 13280A**: Lower control arm nut.
- 92081**: Lower control arm nut.
- 21039**: Lower control arm nut.
- 92015A**: Lower control arm nut.
- 16073**: Lower control arm nut.
- 92072**: Lower control arm nut.

2005 ZZR1200

PARTS LIST

Generator

ITEM NAME	PART NUMBER	QUANTITY
HOLDER,COVER (Ref # 13091)	13091-1327	1
HOLDER,BEARING (Ref # 13091A)	13091-1748	1
HOUSING,FRAME (Ref # 13227)	13227-1143	1
HOLDER,RECTIFIER (Ref # 13280)	13280-1291	1
HOLDER,BRUSH (Ref # 13280A)	13280-1292	1
PLATE-POSITION (Ref # 14014)	14014-1105	1
INSULATOR,TERMINAL (Ref # 16073)	16073-1127	1
COVER-ASSY,END,RR (Ref # 16146)	16146-1232	1
GENERATOR (Ref # 21001)	21001-1192	1
ROTOR (Ref # 21007)	21007-1420	1
BRUSH,CARBON (Ref # 21039)	21039-1052	2
REGULATOR-VOLTAGE (Ref # 21066)	21066-1136	1
WIRE-LEAD (Ref # 26011)	26011-1846	1
FRAME,END,RR (Ref # 31011)	31011-1088	1
STUD (Ref # 92004)	92004-1196	2
SCREW (Ref # 92009)	92009-1645	4
NUT (Ref # 92015)	92015-1851	2
NUT (Ref # 92015A)	92015-2271	2
BEARING-BALL,#6003 (Ref # 92045)	92045-1248	1
SEAL-OIL (Ref # 92049)	92049-1484	1
RING-O,70.6X2.4 (Ref # 92055)	92055-1366	1
BAND (Ref # 92072)	92072-1436	1
SPRING,BRUSH (Ref # 92081)	92081-1759	2
SEAL,RING (Ref # 92093)	92093-1587	1
SEAL,RING (Ref # 92093A)	92093-1588	3
SCREW,4X6 (Ref # 92151)	92151-1245	6
BOLT,M8X65 (Ref # 92153)	92153-1111	3
BOLT (Ref # 92153A)	92153-1241	1
BOLT (Ref # 92153B)	92153-1242	2

2005 ZZR1200

PARTS LIST

Generator



ITEM NAME	PART NUMBER	QUANTITY
BOLT (Ref # 92153C)	92153-1243	3