


# 2004 Ninja® ZX™-6RR

## PARTS DIAGRAM

### Front Wheel

**Kawasaki**  
Let the Good Times Roll®



# 2004 Ninja® ZX™-6RR

## PARTS LIST

### Front Wheel

| ITEM NAME                          | PART NUMBER   | QUANTITY |
|------------------------------------|---------------|----------|
| BEARING-BALL,#6005UU (Ref # 601)   | 601B6005UU    | 2        |
| AXLE,FR (Ref # 41068)              | 41068-1426    | 1        |
| WHEEL-ASSY,FR,BLACK (Ref # 41073)  | 41073-1689-R2 | 1        |
| SEAL-OIL,BJN 32 47 5 (Ref # 92049) | 92049-1377    | 2        |
| COLLAR,NUT,24MM (Ref # 92152)      | 92152-1464    | 1        |
| COLLAR,FR AXLE,L=13 (Ref # 92152A) | 92152-1470    | 2        |
| COLLAR,FR HUB,L=115 (Ref # 92152B) | 92152-1471    | 1        |