

## Handlebar

**Let the Good Times Roll®**

Diagram illustrating the assembly of a motorcycle engine and chassis components. The diagram shows the engine, transmission, swingarm, and various mounting brackets and fasteners. Key components and their labels include:

- Engine and Transmission:** 39087, 39156, 14093, 14093A, 410, 92039, 92154, 92022, 92154, 92072, 92037, 39058, 13107A, 92200, 46012A, 92022A, 13272, 155, 550, 92015, 92145, 46102, 92028, 46012, 92002, 92039A, 13107, 13168.
- Chassis and Mounting:** 27048, 92072A, 220, 39074, 92192, 220.
- Fasteners and Hardware:** 410, 92154, 92028, 92002, 92039A, 13107, 13168, 92072, 92037, 39058, 13107A, 92200, 46012A, 92022A, 13272, 155, 550, 92015, 92145, 46102, 92028, 46012, 92002, 92039A, 13107, 13168.

The diagram includes a "FRONT" arrow indicating the orientation of the assembly. Letters A, B, and C are used to denote specific sub-assemblies or components.

# 2025 Ultra 310LX

## PARTS LIST

### Handlebar

| ITEM NAME                                | PART NUMBER   | QUANTITY |
|------------------------------------------|---------------|----------|
| SHAFT (Ref # 13107)                      | 13107-3795    | 1        |
| SHAFT,HANDLE HOLDER PIVOT (Ref # 13107A) | 13107-3803    | 1        |
| LEVER (Ref # 13168)                      | 13168-3754    | 1        |
| PLATE (Ref # 13272)                      | 13272-3972    | 1        |
| COVER,HANDLE,FR (Ref # 14093)            | 14093-1176    | 1        |
| COVER,HANDLE,RR (Ref # 14093A)           | 14093-1177    | 1        |
| SWITCH-ASSY,STOP&START (Ref # 27048)     | 27048-0054    | 1        |
| HANDLE-COMP,BLACK (Ref # 39058)          | 39058-0044-6Z | 1        |
| LEVER-ASSY-THROTTLE (Ref # 39074)        | 39074-0014    | 1        |
| PAD-HANDLE,BLACK (Ref # 39087)           | 39087-0016-6Z | 1        |
| PAD (Ref # 39156)                        | 39156-2768    | 1        |
| HOLDER-HANDLE,LWR (Ref # 46012)          | 46012-3730    | 1        |
| HOLDER-HANDLE,UPP (Ref # 46012A)         | 46012-3733    | 1        |
| ROD,HANDLE POSITION (Ref # 46102)        | 46102-3733    | 1        |
| BOLT,8X25 (Ref # 92002)                  | 92002-3774    | 4        |
| NUT,CASTLE,14MM (Ref # 92015)            | 92015-3805    | 1        |
| WASHER,6.5X20X1.5 (Ref # 92022)          | 92022-3710    | 2        |
| WASHER,15X34X2.0 (Ref # 92022A)          | 92022-3738    | 1        |
| BUSHING (Ref # 92028)                    | 92028-3743    | 2        |
| CLAMP,HANDLEBAR (Ref # 92037)            | 92037-503     | 2        |
| RIVET (Ref # 92039)                      | 92039-3787    | 4        |
| RIVET (Ref # 92039A)                     | 92039-3788    | 2        |
| BAND,L=188.85 (Ref # 92072)              | 92072-0105    | 4        |
| BAND,TETHER SWITCH (Ref # 92072A)        | 92072-0891    | 1        |
| SPRING (Ref # 92145)                     | 92145-3723    | 2        |
| BOLT,SOCKET,6X14 (Ref # 92154)           | 92154-3988    | 8        |
| TUBE,35X37X200 (Ref # 92192)             | 92192-1990    | 1        |
| WASHER,21X34X2 (Ref # 92200)             | 92200-3802    | 1        |
| NUT,6MM (Ref # 92210)                    | 92210-3768    | 2        |

# 2025 Ultra 310LX

## PARTS LIST

### Handlebar



| ITEM NAME                          | PART NUMBER | QUANTITY |
|------------------------------------|-------------|----------|
| BOLT-WSP-SMALL,8X50 (Ref # 155)    | 155R0850    | 4        |
| SCREW-PAN-CROS,5X30 (Ref # 220)    | 220R0530    | 6        |
| WASHER-PLAIN-SMALL,6MM (Ref # 410) | 410S0600    | 6        |
| PIN-COTTER,3X35 (Ref # 550)        | 550S3035    | 1        |