

Control

Let the Good Times Roll®

Exploded view diagram of a motorcycle engine and chassis assembly. The diagram shows the engine, crankcase, frame, and various components like the generator/ignition coil, gear change mechanism, and gear box. The diagram includes numerous part numbers and labels for assembly reference.

Labels and Part Numbers:

- 130, 411, 14091, 16171, 16171A, 92028, 130C, 130A, 92022, 49113A, 92145A, 92009, 220, 92144, 92152, 92002, 39129, 49103, 411A, 311, Ref. Gear Change Mechanism, Ref. Gear Box, Ref. Crankcase, Ref. Frame, 21177, 92001, 92039, 92039, 14091A, 92145, 130B, (A), (B)

Assembly Notes:

- Ref. Generator/Ignition Coil
- Ref. Crankcase
- Ref. Frame
- Ref. Gear Change Mechanism
- Ref. Gear Box

2019 MULE SX™ 4x4 FI

PARTS LIST

Control



ITEM NAME	PART NUMBER	QUANTITY
-----------	-------------	----------