

Oil Pump/Oil Filter

Let the Good Times Roll®

Exploded view diagram of a crankcase assembly. The diagram shows the crankcase (labeled "Ref. Crankcase") and various components that fit into it. A "FRONT" arrow points to the left. The components and their part numbers are:

- 16142
- 16154
- 13107
- 92042
- 480
- 92200
- 13234
- 551
- 16160
- 92055B
- 92043A
- 92043
- 16142A
- 92153
- 11061
- 132
- 92153
- 92153
- 92170
- 16097
- 32033
- 59256
- 49063
- 92049
- 92055A
- 551
- 92002
- 92022
- 92043A
- 92055
- 16130
- 49065

The diagram also includes a "FRONT" arrow pointing to the left and a "Ref. Crankcase" label pointing to the main assembly.

2006 Ninja® ZX™-6R

PARTS LIST

Oil Pump/Oil Filter

ITEM NAME	PART NUMBER	QUANTITY
BOLT-FLANGED-SMALL,6X12 (Ref # 132)	132L0612	1
CIRCLIP-TYPE-C,11MM (Ref # 480)	480J1100	1
PIN-DOWEL,4X8 (Ref # 551)	551A0408	2
GASKET (Ref # 11061)	11061-0107	1
SHAFT,LH (Ref # 13107)	13107-0072	1
SHAFT-COMP,RH (Ref # 13234)	13234-0012	1
FILTER-ASSY-OIL (Ref # 16097)	16097-0002	1
VALVE-ASSY-RELIEF (Ref # 16130)	16130-1058	1
COVER-PUMP,OIL (Ref # 16142)	16142-0017	1
COVER-PUMP,WATER (Ref # 16142A)	16142-0018	1
ROTOR-PUMP (Ref # 16154)	16154-1124	1
BODY,OIL PUMP (Ref # 16160)	16160-0068	1
PIPE,OIL FILTER (Ref # 32033)	32033-1535	1
SEAL-MECHANICAL,WATER (Ref # 49063)	49063-1055	1
FILTER-OIL (Ref # 49065)	49065-0008	1
IMPELLER (Ref # 59256)	59256-1074	1
BOLT,6X22 (Ref # 92002)	92002-1154	1
WASHER,6.1X12X1 (Ref # 92022)	92022-077	1
PIN,DOWEL,4X15.8 (Ref # 92042)	92042-014	1
PIN,4.2X6X12 (Ref # 92043)	92043-1262	1
PIN,6.2X8X14 (Ref # 92043A)	92043-1263	2
SEAL-OIL,SC 11 28.55 5 (Ref # 92049)	92049-1336	1
RING-O,OIL FILTER (Ref # 92055)	92055-1503	1
RING-O,WATER PUMP COVER (Ref # 92055A)	92055-1532	1
RING-O,59.6X2.4 (Ref # 92055B)	92055-3018	1
BOLT,6X60 (Ref # 92153)	92153-0780	3
CLAMP (Ref # 92170)	92170-1514	1
WASHER,11.3X21X1.6 (Ref # 92200)	92200-0041	1