

# Crankcase

**Let the Good Times Roll®**

Exploded view diagram of a vehicle's rear differential assembly. The diagram shows the main assembly and an inset view of the LH Side (Left Hand Side) of the differential housing (14080A).

**FRONT** (indicated by an arrow pointing towards the top left)

**Part Numbers and Components:**

- 92150, 11009, 39193, 92004, 92043, 14080, 92153, 92043, 92191, 92062, 92171, 32151, 92045A, 235, 235A, 92045, 601, 92043, 92004, 92043, 14080A, 92046, 92045, 13070, 220, 92043, 92051, 11061, 92066, 92049, 92154, 132, 92154A, 132A.

# 2026 KLX<sup>®</sup>110R L

## PARTS LIST

### Crankcase



| ITEM NAME | PART NUMBER | QUANTITY |
|-----------|-------------|----------|
|-----------|-------------|----------|