

# Crankcase

**Let the Good Times Roll®**

This diagram illustrates the exploded view of the engine block and cylinder head assembly. The components are labeled as follows:

- 92192**: A hose or pipe assembly with a "FRONT" arrow indicating orientation.
- 92170**: Two hose end fittings or clamps.
- 92005**: Two cylindrical components, likely O-rings or seals, positioned between the block and head.
- 14101**: The main engine block and cylinder head assembly.
- 92062**: A small bolt or screw.
- 92062A**: A small bolt or screw, slightly different from 92062.
- 92043**: Two cylindrical components, likely O-rings or seals, positioned between the block and head.
- 92066**: Two small bolts or screws.
- 92066A**: Two small bolts or screws, slightly different from 92066.
- 92068**: A small bolt or screw.

# 2024 RIDGE® RANCH EDITION

## PARTS LIST

### Crankcase



| ITEM NAME                      | PART NUMBER | QUANTITY |
|--------------------------------|-------------|----------|
| SET-CRANKCASE (Ref # 14101)    | 14101-0010  | 1        |
| FITTING,BREATHER (Ref # 92005) | 92005-1238  | 3        |
| PIN,10X14 (Ref # 92043)        | 92043-1506  | 3        |
| NOZZLE (Ref # 92062)           | 92062-0004  | 4        |
| NOZZLE (Ref # 92062A)          | 92062-0046  | 1        |
| PLUG (Ref # 92066)             | 92066-0831  | 3        |
| PLUG (Ref # 92066A)            | 92066-3779  | 1        |
| CLAMP (Ref # 92170)            | 92170-1060  | 2        |
| TUBE,BLOWBY GAS (Ref # 92192)  | 92192-2972  | 1        |