

Air Cleaner

Let the Good Times Roll®

Exploded view diagram of the front suspension assembly, showing various components and their assembly sequence. The diagram includes a "FRONT" arrow indicating the orientation.

Key components and assembly steps shown:

- Top Components:** 11010, 11011, 92093, 11029.
- Assembly A:** 92170A, 14073C, 92170A, 14073B.
- Assembly B:** 130, 92143, 92171, 92171A, 49006.
- Assembly C:** 92171B, 14073, 92171B, 12026.
- Assembly D:** 92161B, 92161A, 92161.
- Assembly E:** 92161C, 92192, 92171A, 49006.
- Assembly F:** 92170, 14073A, 92037.

The diagram illustrates the assembly of the front suspension, including the upper control arm, lower control arm, and the associated mounting hardware and bushings.

2023 TERYX4™

PARTS LIST

Air Cleaner

ITEM NAME	PART NUMBER	QUANTITY
FILTER-ASSY-AIR (Ref # 11010)	11010-1873	1
CASE-AIR FILTER (Ref # 11011)	11011-0784	1
ELEMENT-ASSY-AIR FILTER (Ref # 11029)	11029-0740	1
CHAMBER (Ref # 12026)	12026-0016	1
DUCT,JOINT,A/C SIDE (Ref # 14073)	14073-0757	1
DUCT,THROTTLE-CHAMBER (Ref # 14073A)	14073-0758	2
DUCT,INTAKE (Ref # 14073B)	14073-0767	1
DUCT,JOINT (Ref # 14073C)	14073-1775	1
BOOT (Ref # 49006)	49006-1351	2
CLAMP (Ref # 92037)	92037-1523	2
SEAL (Ref # 92093)	92093-0585	1
COLLAR (Ref # 92143)	92143-1087	4
DAMPER,CHAMBER,RH,RR (Ref # 92161)	92161-1518	1
DAMPER,CHAMBER,RH,FR (Ref # 92161A)	92161-1519	1
DAMPER,CHAMBER,LH,RR (Ref # 92161B)	92161-1520	1
DAMPER,CHAMBER,LH,FR (Ref # 92161C)	92161-1521	1
CLAMP (Ref # 92170)	92170-1676	2
CLAMP (Ref # 92170A)	92170-1764	2
CLAMP (Ref # 92171)	92171-0225	6
CLAMP (Ref # 92171A)	92171-1277	2
CLAMP (Ref # 92171B)	92171-3716	2
TUBE,4X8X143 (Ref # 92192)	92192-1230	1
BOLT-FLANGED,6X16 (Ref # 130)	130AA0616	4