


Crankcase

Let the Good Times Roll®

This exploded view diagram illustrates the assembly of a motorcycle engine. The main components shown include:

- Cylinder Head Assembly:** Located at the top right, featuring parts like 92046B, 92066, 92066A, 92046C, 92043, 92045D, 92045E, 92045C, 92045B, 92049, 481, 92046, 92055, 670A, 92043, 92046B, 92046C, 92043, 92045, 92045E, 92045C, 92045B, 92049, 481, 92046, 92055, 670A.
- Piston and Connecting Rod Assembly:** Located in the center, featuring parts like 14014A, 92154A, 92045B, 92045D, 92045C, 92045E, 92045, 92045E, 92045C, 92045B, 92049, 481, 92046, 92055, 670A.
- Valve Train Assembly:** Located on the left, featuring parts like 14014C, 92154A, 14014B, 92154A, 14014, 92037, 132, 92046A, 14014, 92154A, 92045A, 92065, 92066B, 14101, 92066, 92066A, 92046B, 92046C, 92043, 92045, 92045E, 92045C, 92045B, 92049, 481, 92046, 92055, 670A.
- Other Components:** Various small parts like 92046B, 92066, 92066A, 92046C, 92043, 92045D, 92045E, 92045C, 92045B, 92049, 481, 92046, 92055, 670A, 92043, 92046B, 92046C, 92043, 92045, 92045E, 92045C, 92045B, 92049, 481, 92046, 92055, 670A.

The diagram uses letters A, B, C, and D to indicate specific assembly points or orientations. A "FRONT" arrow is located at the top left corner.



2024 Teryx4™ S Special Edition

PARTS LIST

Crankcase

ITEM NAME	PART NUMBER	QUANTITY
GASKET,8.2X15 (Ref # 11061)	11061-0727	2
PLATE-POSITION (Ref # 14014)	14014-0553	1
PLATE-POSITION (Ref # 14014A)	14014-0554	1
PLATE-POSITION (Ref # 14014B)	14014-0555	1
PLATE-POSITION (Ref # 14014C)	14014-0557	3
SET-CRANKCASE (Ref # 14101)	14101-0026	1
CLAMP (Ref # 92037)	92037-1993	1
PIN,10X14 (Ref # 92043)	92043-1506	2
BEARING-BALL,63/22LUA (Ref # 92045)	92045-0704	1
BEARING-BALL,6904 (Ref # 92045A)	92045-0705	1
BEARING-BALL,6308YA3-T2C3 (Ref # 92045B)	92045-0706	1
BEARING-BALL,TMB304LUA (Ref # 92045C)	92045-0743	1
BEARING-BALL,63/32C3 (Ref # 92045D)	92045-1364	1
BEARING-BALL,6303LUA (Ref # 92045E)	92045-1389	1
BEARING-NEEDLE (Ref # 92046)	92046-0022	1
BEARING-NEEDLE,HK1210FM (Ref # 92046A)	92046-0034	1
BEARING-NEEDLE,BA13178ZE01 (Ref # 92046B)	92046-0048	2
BEARING-NEEDLE,7E-HKS33X38X8 (Ref # 92046C)	92046-1221	1
SEAL-OIL,25X45X9.5 (Ref # 92049)	92049-0739	1
RING-O,33X2.6 (Ref # 92055)	92055-0723	1
RING-O,31.2X2.4 (Ref # 92055A)	92055-0724	1
GASKET,12X22X2 (Ref # 92065)	92065-097	1
PLUG,PT1/8X7 (Ref # 92066)	92066-0863	5
PLUG,BREATHER (Ref # 92066A)	92066-1035	1
PLUG,OIL DRAIN,12X15 (Ref # 92066B)	92066-1174	1
BOLT,FLANGED,8X95 (Ref # 92154)	92154-0835	2
BOLT,TORX,6X11.7 (Ref # 92154A)	92154-1821	10
BOLT-FLANGED-SMALL,6X12 (Ref # 132)	132BA0612	1
BOLT-FLANGED-SMALL,6X40 (Ref # 132A)	132BD0640	5

2024 Teryx4™ S Special Edition



PARTS LIST

Crankcase

ITEM NAME	PART NUMBER	QUANTITY
BOLT-FLANGED-SMALL,6X55 (Ref # 132B)	132BD0655	5
BOLT-FLANGED-SMALL,8X75 (Ref # 132C)	132BD0875	9
CIRCLIP-TYPE-C,37MM (Ref # 481)	481J3700	1
O RING,22MM (Ref # 670)	670B2022	1
O RING,16MM (Ref # 670A)	670D2016	1