


# 2026 VERSYS®-X 300 ABS

## PARTS DIAGRAM

### Transmission



# 2026 VERSYS®-X 300 ABS

## PARTS LIST

### Transmission

ITEM NAME	PART NUMBER	QUANTITY
SHAFT-TRANSMISSION INPUT (Ref # 13127)	13127-0668	1
SHAFT-TRANSMISSION OUTPUT (Ref # 13128)	13128-0693	1
SPROCKET-OUTPUT,14T (Ref # 13144)	13144-0577	1
GEAR,INPUT 2ND,19T (Ref # 13262)	13262-0461	1
GEAR,INPUT 3RD&4TH,22T&25T (Ref # 13262A)	13262-0464	1
GEAR,OUTPUT 3RD,31T (Ref # 13262B)	13262-0466	1
GEAR,OUTPUT 4TH,29T (Ref # 13262C)	13262-0467	1
GEAR,OUTPUT 2ND,34T (Ref # 13262D)	13262-0468	1
GEAR,OUTPUT 5TH,27T (Ref # 13262E)	13262-0470	1
GEAR,OUTPUT LOW,38T (Ref # 13262F)	13262-0921	1
GEAR,INPUT 5TH,27T (Ref # 13262G)	13262-0922	1
GEAR,INPUT 6TH,28T (Ref # 13262H)	13262-1265	1
GEAR,OUTPUT 6TH,24T (Ref # 13262I)	13262-1321	1
NUT,20MM (Ref # 92015)	92015-1963	1
WASHER,20.5X30X1,STEEL (Ref # 92022)	92022-112	2
WASHER,25.3X30X1 (Ref # 92022A)	92022-161	2
BUSHING,9.4X25X28 (Ref # 92028)	92028-1564	1
BUSHING,OUTPUT 3RD&4TH GEAR (Ref # 92028A)	92028-1858	1
RING-SNAP,20MM (Ref # 92033)	92033-015	2
RING-SNAP,24MM (Ref # 92033A)	92033-026	6
BEARING-BALL,6TM-6205NX3 (Ref # 92045)	92045-0735	1
BEARING-BALL,#6205NX3 (Ref # 92045A)	92045-1013	1
BEARING-NEEDLE,20X25X12.8 (Ref # 92046)	92046-0607	2
BUSHING,26X28X16.6 (Ref # 92139)	92139-0781	1
BUSHING,25X28X10.4 (Ref # 92139A)	92139-0793	1
BUSHING,25X33X14 (Ref # 92139B)	92139-0872	2
COLLAR,SPROCKET (Ref # 92143)	92143-1968	1
WASHER (Ref # 92200)	92200-0851	1
WASHER (Ref # 92200A)	92200-1389	4

# 2026 VERSYS<sup>®</sup>-X 300 ABS

## PARTS LIST

### Transmission



ITEM NAME	PART NUMBER	QUANTITY
BALL-STEEL,5/32 (Ref # 600)	600A0500	3