


# 2026 Eliminator ABS

## PARTS DIAGRAM

### Front Wheel



# 2026 Eliminator ABS

## PARTS LIST

### Front Wheel

| ITEM NAME                           | PART NUMBER   | QUANTITY |
|-------------------------------------|---------------|----------|
| CAP,AXLE NUT (Ref # 11012)          | 11012-1592    | 1        |
| AXLE,FR (Ref # 41068)               | 41068-0662    | 1        |
| WHEEL-ASSY,FR,G.BLACK (Ref # 41073) | 41073-0839-QT | 1        |
| SEAL-OIL,23X40X7 (Ref # 92049)      | 92049-0801    | 2        |
| COLLAR,17X30X15.5 (Ref # 92152)     | 92152-2386    | 2        |
| COLLAR,17.2X25X125 (Ref # 92152A)   | 92152-2935    | 1        |
| WASHER,17.3X30X2 (Ref # 92200)      | 92200-1916    | 1        |
| NUT,CASTLE,16X19 (Ref # 92210)      | 92210-1585    | 1        |
| PIN-COTTER,4.0X35 (Ref # 550)       | 550AA4035     | 1        |
| BEARING-BALL,#6203UUC3 (Ref # 601)  | 601B6203UU    | 2        |