


1987 Tecate 4

PARTS DIAGRAM

Cylinder Head/Cylinder

E1110-0040



1987 Tecate 4

PARTS LIST

Cylinder Head/Cylinder

ITEM NAME	PART NUMBER	QUANTITY
HEAD-CYLINDER (Ref # 11001)	11001-1259	1
GASKET-HEAD (Ref # 11004)	11004-1157	1
CYLINDER-ENGINE (Ref # 11005)	11005-1528	1
GASKET, REED VALVE (Ref # 11009)	11009-1252	1
GASKET, CYLINDER BASE (Ref # 11009A)	11009-1624	1
GASKET, GOVERNOR COVER (Ref # 11009B)	11009-1625	1
GASKET, 12.5X18X1, DRAIN PLUG (Ref # 11009C)	92065-073	1
VALVE-EXHAUST, LH (Ref # 12005)	12005-1094	1
VALVE-EXHAUST, RH (Ref # 12005A)	12005-1095	1
VALVE-ASSY-REED (Ref # 12021)	12021-1071	1
VALVE-REED (Ref # 12022)	12022-1060	2
COVER, GOVERNOR (Ref # 14024)	14024-1359	1
HOSE-COOLING, PUMP-CYLINDER (Ref # 39062)	39062-1233	1
GUIDE-VALVE (Ref # 49002)	49002-1073	2
GUIDE-VALVE (Ref # 49002A)	49002-1074	1
GUIDE-VALVE (Ref # 49002C)	49002-1087	1
ROD-GOVERNOR (Ref # 49046)	49046-1060	1
BOLT, 6X10 (Ref # 92002)	92002-1222	1
STUD, 8X40 (Ref # 92004)	92004-1139	7
SCREW, 3X6 (Ref # 92009)	92009-1371	8
SCREW, 5X10 (Ref # 92009A)	92009-1502	1
NUT, FLANGED, 10MM (Ref # 92015)	92015-077	4
NUT, 8MM (Ref # 92015A)	92015-1143	7
WASHER, 8.2X14X1 (Ref # 92022)	92022-1488	1
WASHER, 6.8X16X0.5 (Ref # 92022A)	92022-1869	2
WASHER, 6.2X11X1 (Ref # 92022B)	92022-304	1
CLAMP, WIRING HARNESS (Ref # 92037)	92037-1069	1
CLAMP, COOLING HOSE (Ref # 92037A)	92037-1589	2
SEAL-OIL, RSO-5.5X11X4 (Ref # 92049)	92049-1206	1

1987 Tecate 4

PARTS LIST

Cylinder Head/Cylinder

ITEM NAME	PART NUMBER	QUANTITY
RING-O,17.5X1.5 (Ref # 92055)	92055-022	2
RING-O,10X1.5 (Ref # 92055A)	92055-061	1
RING-O,11.5X1.5 (Ref # 92055C)	92055-1387	1
PLUG,12X10 (Ref # 92066)	92066-1222	1
COLLAR (Ref # 92143)	92143-1056	1
BOLT-FLANGED (Ref # 130)	130G0535	2
BOLT-FLANGED-SMALL (Ref # 132)	132G0625	3
BOLT-FLANGED-SMALL (Ref # 132A)	132G0810	1
CIRCLIP-TYPE-E,4MM (Ref # 482)	482J4000	2