

1987 Tecate 4


PARTS DIAGRAM

Crankcase

Kawasaki

Let the Good Times Roll®

E1411-0172



1987 Tecate 4

PARTS LIST

Crankcase

ITEM NAME	PART NUMBER	QUANTITY
GASKET,10.5X16X1,DRAIN PLUG (Ref # 11009)	92065-058	1
GUIDE-KICK (Ref # 13206)	13206-1001	1
SET-CRANKCASE (Ref # 14001)	14001-5233	1
BREATHER (Ref # 14069)	14069-003	1
BOLT,W/WASHER,6X14 (Ref # 92001)	92001-1829	2
BOLT,8X15 (Ref # 92002)	92002-1601	1
BOLT,6X16 (Ref # 92002A)	92002-1659	2
STUD,10X65 (Ref # 92004)	92004-1032	2
STUD,10X53 (Ref # 92004A)	92004-1165	2
WASHER (Ref # 92022)	92022-1865	2
CLAMP,HARNESS (Ref # 92037)	92037-1318	1
PIN,DOWEL,6.3X8X14 (Ref # 92043)	92042-007	2
BEARING-BALL,#6905 (Ref # 92045)	92045-036	1
BEARING-BALL,#626 (Ref # 92045A)	92045-1010	1
BEARING-BALL,6205 (Ref # 92045B)	92045-1115	1
BEARING-BALL,16008 (Ref # 92045C)	92045-1116	1
BEARING-BALL,63/22T2C3 (Ref # 92045D)	92045-1134	1
BEARING-BALL,6203SH2C3 (Ref # 92045E)	92045-1193	1
BEARING-BALL,TMB204C3 (Ref # 92045F)	92045-1194	1
BEARING-BALL (Ref # 92045G)	92045-1205	2
SEAL-OIL,TCJ25457 (Ref # 92049)	92049-1051	2
SEAL-OIL,TB3040 (Ref # 92049A)	92050-033	1
SEAL-OIL,TB13225.5 (Ref # 92049B)	92051-005	1
TUBE,6X9X630 (Ref # 92059)	92059-1953	1
PLUG,DRAIN (Ref # 92066)	92066-1241	1
BOLT-FLANGED-SMALL (Ref # 132)	132G0612	2
BOLT-FLANGED-SMALL (Ref # 132A)	132G0616	1
BOLT-FLANGED-SMALL (Ref # 132B)	132G0650	10