


1988 Tecate 4

PARTS DIAGRAM

Handlebar



1988 Tecate 4

PARTS LIST

Handlebar

ITEM NAME	PART NUMBER	QUANTITY
CAP (Ref # 11012)	11012-1425	1
BRACKET-A,LEVER HOLDER (Ref # 11036)	11036-1297	1
WEIGHT,HANDLE (Ref # 13042)	13042-1060	2
HOLDER,LEVER (Ref # 13091)	13091-1456	1
COVER,PARKING LEVER (Ref # 14024)	14024-1351	1
ARM (Ref # 21083)	21083-1068	1
LEVER-ASSY-THROTTLE (Ref # 39074)	39074-1052	1
LEVER-THROTTLE (Ref # 39075)	39075-1053	1
LEVER-THROTTLE ARM (Ref # 39075A)	39075-1054	1
PAD-HANDLE (Ref # 39087)	39087-1054	1
HANDLE (Ref # 46003A)	46003-1272	1
HOLDER-HANDLE,UPP (Ref # 46012)	46012-008	2
GRIP (Ref # 46075)	46075-1056	2
LEVER-ASSY-GRIP,LH (Ref # 46076)	46076-1151	1
HOUSING-ASSY-CONTROL,LH (Ref # 46091)	46091-1444	1
LEVER-GRIP,CLUTCH (Ref # 46092)	46092-1137	1
LEVER-GRIP,PARKING (Ref # 46092A)	46092-1138	1
BOOT,LH (Ref # 49006)	49006-1197	1
BOOT,RH (Ref # 49006A)	49006-1198	1
BOLT,LEVER SET (Ref # 92002)	92002-1833	1
BOLT,TAPPING (Ref # 92002A)	92002-1834	1
SCREW,CABLE ADJUST,8MM (Ref # 92009)	46055-009	1
NUT,CABLE ADJUST (Ref # 92015)	46056-006	1
NUT,LOCK,6MM (Ref # 92015A)	92019-008	1
COLLAR,6.3X10X4.8 (Ref # 92027)	92027-1066	2
PIN,5X15 (Ref # 92043)	92043-1341	1
PIN,5X11 (Ref # 92043A)	92043-1342	1
BAND,L=123 (Ref # 92072)	92072-030	1
KNOB,PARKING LEVER (Ref # 92077)	92077-1076	1

1988 Tecate 4

PARTS LIST

Handlebar

ITEM NAME	PART NUMBER	QUANTITY
COLLAR (Ref # 92143)	92143-1138	2
SPRING (Ref # 92144)	92144-1058	3
SPRING (Ref # 92144A)	92144-1176	1
BOLT-UPSET (Ref # 112)	112D0614	1
BOLT-FLANGED (Ref # 130)	130J0860	4
SCREW-PAN-CROS (Ref # 220)	220B0535	2
SCREW-PAN-CROS (Ref # 220A)	220C0514	2
SCREW-PAN-CROS (Ref # 220B)	220C0525	2
SCREW-PAN-CROS,6X30,BLACK (Ref # 220C)	220C0630	1
SCREW-CSK-RD-CROS (Ref # 222)	222C0640	2
NUT-HEX,6MM,BLACK (Ref # 312)	312C0600	1
WASHER-PLAIN,6MM (Ref # 411)	411E0600	1
WASHER-SPRING (Ref # 461)	461L0600	1