



1987 Tecate 4

PARTS DIAGRAM

Ignition Switch

F2770-0331



1987 Tecate 4

PARTS LIST

Ignition Switch

ITEM NAME

PART NUMBER

QUANTITY
