


2026 JET SKI® STX® 160LX

PARTS DIAGRAM

Fuel Injection



2026 JET SKI® STX® 160LX

PARTS LIST

Fuel Injection

ITEM NAME	PART NUMBER	QUANTITY
BRACKET,BEARING CASE (Ref # 11058)	11058-2094	1
BRACKET,MAGNETIC SWITCH (Ref # 11058A)	11058-2096	1
BRACKET (Ref # 11058B)	11058-2322	1
HOLDER (Ref # 13280)	13280-0789	1
REGULATOR-VOLTAGE (Ref # 21066)	21066-0755	1
CONTROL UNIT-ELECTRONIC (Ref # 21175)	21175-2142	1
SENSOR,TEMP (Ref # 21176)	21176-0741	2
FUSE-ASSY,15A (Ref # 26004)	26004-0041	4
FUSE-ASSY,20A (Ref # 26004A)	26004-0042	4
HARNESS,MAIN (Ref # 26031)	26031-4242	1
RELAY-ASSY (Ref # 27002)	27002-3703	3
SWITCH,MAGNETIC (Ref # 27010)	27010-1518	1
SWITCH,VDS (Ref # 27010A)	27010-3785	1
BOLT,6X12 (Ref # 92002)	92002-3763	2
WASHER,6.5X20X1.5 (Ref # 92022)	92022-3710	2
CLAMP,L=100 (Ref # 92037)	92037-3736	2
GROMMET (Ref # 92071)	92071-0863	1
BAND,L=188.85 (Ref # 92072)	92072-0105	3
BAND,OS170-FT7(BLACK) (Ref # 92072A)	92072-1414	AR
BAND,L=372.24 (Ref # 92072B)	92072-3883	6
CLAMP (Ref # 92173)	92173-0742	2
BOLT,6X8 (Ref # 110)	110R0608	2
BOLT-FLANGED,6X10 (Ref # 130)	130R0610	2
BOLT-WP,6X14 (Ref # 156)	156R0614	2
BOLT-WP,6X16 (Ref # 156A)	156R0616	5
BOLT-WP,6X18 (Ref # 156B)	156R0618	2
BOLT-WP,6X20 (Ref # 156C)	156R0620	2
SCREW-PAN-CROS,4X20 (Ref # 220)	220R0420	2