


2026 NINJA H2[®] ABS

PARTS DIAGRAM

Fuel Tank



2026 NINJA H2® ABS

PARTS LIST

Fuel Tank

ITEM NAME	PART NUMBER	QUANTITY
BREATHER,TANK (Ref # 14069)	14069-0008	1
COVER,KNEE GRIP,LH (Ref # 14093)	14093-0180	1
COVER,KNEE GRIP,RH (Ref # 14093A)	14093-0181	1
COVER-ASSY,TANK,LH,M.C.S.BLACK (Ref # 16146)	16146-0780-53X	1
COVER-ASSY,TANK,RH,M.C.S.BLACK (Ref # 16146B)	16146-0781-53X	1
BRACKET-TANK,RR (Ref # 32052)	32052-0763	1
BRACKET-TANK,FR (Ref # 32052A)	32052-0764	1
PAD,RR FRM (Ref # 39156)	39156-1778	1
PAD,15X20X0.2 (Ref # 39156A)	39156-1784	2
PAD,FUEL TANK,LH (Ref # 39156B)	39156-1942	1
PAD,FUEL TANK,RH (Ref # 39156C)	39156-1943	1
PAD,FUEL TANK (Ref # 39156D)	39156-2940	1
TANK-COMP-FUEL,M.C.S.BLACK (Ref # 51001)	51001-0913-53X	1
CAP-TANK,FUEL (Ref # 51049)	51049-0758	1
TRIM,FUEL TANK (Ref # 53044)	53044-0582	4
NUT,FLANGED,6MM (Ref # 92015)	92015-1367	1
NUT,WELL,5MM (Ref # 92015A)	92015-1757	2
CLAMP,TUBE (Ref # 92037)	92037-010	1
DAMPER,6X16X7 (Ref # 92075)	92075-1011	2
DAMPER,10X24X12 (Ref # 92075A)	92075-1690	2
DAMPER,9X24X14 (Ref # 92075B)	92075-281	3
SEAL,FUEL TANK CAP (Ref # 92093)	92093-1030	1
COLLAR,6.3X10X14.5 (Ref # 92152)	92152-0091	2
COLLAR,6X10X60.2 (Ref # 92152A)	92152-1964	1
BOLT,SOCKET,5X16 (Ref # 92153)	92153-1616	3
BOLT,SOCKET,5X16 (Ref # 92154)	92154-1560	4
BOLT,SOCKET,5X12 (Ref # 92154A)	92154-1561	6
DAMPER,FUEL TANK (Ref # 92161)	92161-1737	2
CLAMP,DRAIN TUBE (Ref # 92173)	92173-1391	1

2026 NINJA H2[®] ABS

PARTS LIST

Fuel Tank

ITEM NAME	PART NUMBER	QUANTITY
TUBE,DRAIN,6X9X808 (Ref # 92192)	92192-1669	1
WASHER,6.5X22X1.6 (Ref # 92200)	92200-1087	2
WASHER,5.2X10X1.0 (Ref # 92200A)	92200-1820	8
BOLT-SOCKET,6X75 (Ref # 120)	120CA0675	1
BOLT-SOCKET,6X16 (Ref # 120A)	120CB0616	4
BOLT-FLANGED,6X22 (Ref # 130)	130CA0622	2
TUBE-RUBBER,6X9X140 (Ref # 702)	702A06140	1
TUBE-RUBBER,6X9X630 (Ref # 702A)	702A06630	1
CLAMP,TUBE (Ref # 92037)	92037-010	4