

Crankcase

Let the Good Times Roll®

Exploded view diagram of a vehicle's rear suspension assembly, showing various components and their part numbers. A "FRONT" arrow points towards the top left. The diagram includes a main assembly view and an inset view labeled "(14080A) (LH Side)" showing a different perspective of the rear suspension housing.

Key components and part numbers shown:

- 92150, 11009, 39193, 92004, 92043, 14080, 92153, 92043, 92191, 92062, 92171, 32151, 92045A, 235, 235A, 92045, 601, 92043, 92004, 92043, 14080A, 92046, 92045, 13070, 220, 92043, 92051, 11061, 92066, 92049, 92154, 92154A.

2027 KLX110L

PARTS LIST

Crankcase

ITEM NAME	PART NUMBER	QUANTITY
GASKET,8.2X14X1.0 (Ref # 11009)	11009-1344	4
GASKET,DRAIN PLUG (Ref # 11061)	11061-0421	1
GUIDE (Ref # 13070)	13070-1319	1
CRANKCASE,RH (Ref # 14080)	14080-0080	1
CRANKCASE,LH (Ref # 14080A)	14080-0705	1
PIPE (Ref # 32151)	32151-1961	1
PIPE-OIL (Ref # 39193)	39193-1042	1
STUD,8X192 (Ref # 92004)	92004-0030	4
PIN,6.2X8X14 (Ref # 92043)	92043-1741	6
BEARING-BALL,6203CE J (Ref # 92045)	92045-0119	2
BEARING-BALL,6804 (Ref # 92045A)	92045-1171	1
BEARING-NEEDLE,HK1312 (Ref # 92046)	92046-1148	1
SEAL-OIL (Ref # 92049)	92049-1429	1
SEAL-OIL,TB13225.5 (Ref # 92051)	92051-005	1
NOZZLE,5X11.5X12 (Ref # 92062)	92062-1090	1
PLUG,OIL DRAIN,12X15 (Ref # 92066)	92066-0768	1
BOLT,BANJO,8X20 (Ref # 92150)	92150-1556	2
BOLT,8X15.5 (Ref # 92153)	92153-1823	1
BOLT,FLANGED,6X50 (Ref # 92154)	92154-7213	5
BOLT,FLANGED,6X75 (Ref # 92154A)	92154-7214	5
CLAMP (Ref # 92171)	92171-1055	1
SCREW,6X12 (Ref # 92172)	92172-1500	1
TUBE,BREATHER (Ref # 92191)	92191-1724	1
SCREW-PAN-CROS,6X14 (Ref # 220)	220AA0614	2
SCREW-PAN-WP-CROS,5X10 (Ref # 235)	235AA0510	2
SCREW-PAN-WP-CROS,6X14 (Ref # 235A)	235AA0614	1
BEARING-BALL (Ref # 601)	601A6201	1
O RING,9.8X1.9 (Ref # 670)	670B1510	2