

Transmission

Let the Good Times Roll®

Exploded view diagram of a mechanical assembly. The diagram shows various components labeled with part numbers, including gears, shafts, bearings, and seals. A "FRONT" arrow is located in the top left corner. The components are arranged in an exploded view, showing their relative positions and assembly sequence.

Key components and part numbers include:

- 13107A: Long shaft
- 13107B: Shaft with gear
- 13107C: Shaft with gear
- 13107D: Shaft with gear
- 13107E: Shaft with gear
- 13262: Gear
- 13262A: Gear
- 13262B: Gear
- 13262C: Gear
- 13262D: Gear
- 13262E: Gear
- 13139: Gear housing
- 59057A: Gear
- 59057: Gear
- 92200: Seal
- 92046: Seal
- 92046A: Seal
- 92046B: Seal
- 92046C: Seal
- 92026: Seal
- 92026A: Seal
- 92026B: Seal
- 92026C: Seal
- 92026D: Seal
- 92145: Seal
- 92152/A~E: Seal
- 92116: Seal
- 480: Seal
- 480A: Seal
- 480B: Seal
- 480C: Seal

2024 MULE PRO-FXT™ 1000 LE

PARTS LIST

Transmission



ITEM NAME	PART NUMBER	QUANTITY
-----------	-------------	----------